

RIGID S-SERIES BEET DEFOLIATOR 2019

ALLOWAY 



RDS 12R22

RDS 8R30

OPERATOR'S MANUAL

TO THE DEALER:

Assembly and proper installation of this product is the responsibility of the Alloway dealer. Read manual instructions and safety rules. Make sure all items on the Dealer's Pre-Delivery and Delivery Check Lists in the Operator's Manual are completed before releasing equipment to the owner.

The dealer must complete the Warranty Registration included in this manual. Both dealer and customer must sign the registration which certifies that all Dealer Check List items have been completed. The dealer is to return the prepaid postage portion to Alloway, give one copy to the customer, and retain one copy.

Note: Warranty credit is subject to this form being completed and returned.

TO THE OWNER:

Read this manual before operating your Alloway equipment. The information presented will prepare you to do a better and safer job. Keep this manual handy for ready reference. Require all operators to read this manual carefully and become acquainted with all the adjustment and operating procedures before attempting to operate. Replacement manuals can be obtained from your dealer.

The equipment you have purchased has been carefully engineered and manufactured to provide dependable and satisfactory use. Like all mechanical products, it will require cleaning and upkeep. Lubricate the unit as specified. Observe all safety information in this manual and safety decals on the equipment.

For service, your authorized Alloway dealer has trained mechanics, genuine Alloway service parts, and the necessary tools and equipment to handle all your needs.

Use only genuine Alloway service parts. Substitute parts will void the warranty and may not meet standards required for safe and satisfactory operation. Record the model number and serial number of your equipment in the spaces provided:

Model: _____ **Date of Purchase** _____

Serial Number: (see Safety Decal section for location) _____

Provide this information to your dealer to obtain correct repair parts.

Throughout this manual, the term **IMPORTANT** is used to indicate that failure to observe can cause damage to equipment. The terms **CAUTION**, **WARNING** and **DANGER** are used in conjunction with the Safety-Alert Symbol, (a triangle with an exclamation mark), to indicate the degree of hazard for items of personal safety.



This Safety-Alert Symbol indicates a hazard and means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**



Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.



WARNING

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed



CAUTION

Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury.

IMPORTANT

Indicates that failure to observe can cause damage to equipment.

NOTE

Indicates helpful information.

ALLOWAY

TABLE OF CONTENTS

INTRODUCTION	Inside Front Cover
GENERAL INFORMATION	1
SPECIFICATIONS	2
SAFETY RULES	3 - 7
SAFETY AND INSTRUCTIONAL DECALS	8 - 9
OPERATOR SIGN-OFF RECORD	11
CHECK LISTS (DEALER'S RESPONSIBILITY)	12
OPERATION	13 - 22
FIELD OPERATION	23 - 26
ADDITIONAL EQUIPMENT (OPTIONAL)	27 - 30
STORAGE	31
SERVICE & MAINTENANCE	32 - 40
TROUBLE SHOOTING	41 - 42
INDEX TO PARTS LISTS	43
BOLT TORQUE CHART	127
ABBREVIATIONS	128
INDEX	129
REPLACEMENT PARTS WARRANTY	130
PRODUCT WARRANTY	Inside Back Cover

GENERAL INFORMATION

The purpose of this manual is to assist you in operating and maintaining your Beet Defoliator. Read it carefully. It furnishes information and instructions that will help you achieve years of dependable performance. These instructions have been compiled from extensive field experience and engineering data. Some information may be general in nature due to unknown and varying operating conditions. However, through experience and these instructions, you should be able to develop procedures suitable to your particular situation.

The illustrations and data used in this manual were current at the time of printing, but due to possible inline production changes, your machine may vary slightly in detail. We reserve the right to redesign and change the machines as may be necessary without notification.



WARNING

- **Some illustrations in this manual show the Beet Defoliator with safety shields removed to provide a better view. The Beet Defoliator should never be operated with any safety shielding removed.**

Throughout this manual, references are made to right and left direction. These are determined by standing behind the equipment facing the direction of forward travel.

SPECIFICATIONS

Number of Rows: 8 - 12

Row Spacing: 20 - 30 in (51 - 76 cm)

Transport Width: 301" (7.6 m)

Transport Height: 69" (1.7 m)

Tractor PTO Speed: 1000 RPM

Tire Size: (Traction Tire) 11.2 X 24

Tire Pressure: 20 PSI (137.9 kPa)

Flail Types: Steel (Cup-knife / L-Knife) or Rubber

Scalper (Rotating Disc Type): Optional

Weight (Cup-Knife): 14,400 lbs (6,545 kg)

Weight (L-Knife): 13,800 lbs (6,273 kg)

Weight (Rubber Flail): 13,200 lbs (6,000 kg)

Weight (Scalper Attachment): 1,679 lbs (763 kg)



SAFETY RULES

ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Safety is a primary concern in the design and manufacture of our products. Unfortunately, our efforts to provide safe equipment can be wiped out by a single careless act of an operator.

In addition to the design and configuration of equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence and proper training of personnel involved in the operation, transport, maintenance and storage of equipment.

It has been said *"The best safety device is an informed, careful operator."* We ask you to be that kind of an operator.

The designed and tested safety of this equipment depends on it being operated within the limitations as explained in this manual.

TRAINING

- **Safety instructions are important! Read all attachment and power unit manuals; follow all safety rules and safety decal information. (Replacement manuals are available from dealer). Failure to follow instructions or safety rules can result in serious injury or death.**

- **If you do not understand any part of this manual and need assistance, see your dealer.**

- **Know your controls and how to stop engine and attachment quickly in an emergency.**

- **Operators must be instructed in and be capable of the safe operation of the equipment, its attachments and all controls. Do not allow anyone to operate this equipment without proper instructions.**

- **Keep hands and body away from pressurized lines. Use paper or cardboard, not body parts to check for leaks. Wear safety goggles. Hydraulic fluid under pressure can easily penetrate skin and will cause serious injury or death.**

- **Make sure that all operating and service personnel know that in the event hydraulic fluid penetrates skin, it must be surgically removed as soon as possible by a doctor familiar with this form of injury, or gangrene, serious injury or death will result. CONTACT A PHYSICIAN IMMEDIATELY IF FLUID ENTERS SKIN OR EYES. DO NOT DELAY.**

- **Never allow children or untrained persons to operate equipment.**

PREPARATION

- **Check that all hardware is tight and properly installed. Always tighten to torque chart specifications unless instructed otherwise in this manual.**

- **Air in hydraulic systems can cause erratic operation and allows loads or equipment components to drop unexpectedly. Before operating or allowing anyone to approach the equipment, purge any air in the system by operating all hydraulic functions several times after connecting equipment, connecting hoses, or doing any hydraulic maintenance.**

- **Make sure all hydraulic hoses, fittings and valves are in good condition and not leaking before starting power unit or using equipment. Check and route hoses carefully to prevent damage. Hoses must not be twisted, bent sharply, kinked, frayed, pinched, or come into contact with any moving parts. Operate moveable components through full operational range to check clearances. Replace any damaged hoses immediately.**

- **Always wear relatively tight and belted clothing to avoid entanglement in moving parts. Wear sturdy, rough-soled work shoes and protective equipment for eyes, hair, hands, hearing and head; and respirator or filter mask where appropriate.**

- **Ensure implement is properly attached, adjusted and in good operating condition.**

- **Make sure spring-activated locking pin or collar slides freely and is seated firmly in tractor PTO spline groove.**

- **Before starting power unit, check all equipment driveline guards for damage and make sure they rotate freely on all drivelines. Replace any damaged guards. If guards do not rotate freely on drivelines, repair and replace bearings before operating.**

(Safety Rules continued on next page)



SAFETY RULES

ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



(Safety Rules continued from previous page)

- Power unit must be equipped with ROPS or ROPS CAB and seat belt. Keep seat belt securely fastened. Falling off power unit can result in death from being run over or crushed. Keep foldable ROPS systems in “locked up” position at all times.
- Connect PTO driveline directly to power unit PTO shaft. Never use adapter sleeves or adapter shafts. Adapters can cause driveline failures due to incorrect spline or incorrect operating length and can result in personal injury or death.
- Inspect rubber flaps and swing rod before each use. Replace if damaged or missing. Flaps must pivot and hang freely so there are no gaps. Do not put equipment into service until repaired.
- Remove accumulated debris from this equipment, tractor and engine to avoid fire hazard.
- Ensure all safety decals are installed. Replace if damaged. (See Safety Decals section for location.)
- Ensure shields and guards are properly installed and in good condition. Replace if damaged.
- A minimum 20% of tractor and equipment weight must be on tractor front wheels when attachments are in transport position. Without this weight, tractor could tip over, causing personal injury or death. The weight may be attained with a loader, front wheel weights, ballast in tires or front tractor weights. When attaining the minimum 20% weight on the front wheels, you must not exceed the Roll Over Protection Structure (ROPS) weight certification. Weigh the tractor and equipment. Do not estimate.
- Make sure hydraulic hoses and cylinders are fully purged of air before operating. Keep all persons away and fill the system by raising and lowering all functions several times. Air in the system can allow components to fall unexpectedly.
- Inspect and clear area of stones, branches, or other hard objects that might be thrown, causing injury or damage.

TRANSPORTING

- Power unit must be equipped with ROPS or ROPS cab and seat belt. Keep seat belt securely fastened. Falling off power unit can result in death from being run over or crushed. Keep foldable ROPS systems in “locked up” position at all times.
- Always sit in power unit seat when operating controls or starting engine. Securely fasten seat belt, place transmission in neutral, engage brake, and ensure all other controls are disengaged before starting power unit engine.
- A minimum 20% of tractor and equipment weight must be on the tractor front wheels when attachments are in transport position. Without this weight, tractor could tip over, causing personal injury or death. The weight may be attained with a loader, front wheel weights, ballast in tires or front tractor weights. Weigh the tractor and equipment. Do not estimate.
- Always attach safety chain to tractor drawbar when transporting unit.
- Always raise unit and install transport locks before transporting. Leak down or failure of mechanical or hydraulic system can cause equipment to drop.
- Never exceed 20 MPH during transport. See the Speed vs. Weight Ratio Table in "Field Operation, Transporting the Unit" for proper tow vehicle to machine weight ratios.
- Watch for hidden hazards on the terrain.
- Always comply with all state and local lighting and marking requirements.
- Never allow riders on power unit or attachment.
- Do not operate PTO during transport.
- Look down and to the rear and make sure area is clear before operating in reverse.
- Do not operate or transport on steep slopes.

(Safety Rules continued on next page)



SAFETY RULES

ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



(Safety Rules continued from previous page)

- Use extreme care and reduce ground speed on slopes and rough terrain.
- Do not operate or transport equipment while under the influence of alcohol or drugs.

OPERATION

- Equipment may be pictured with covers open for instructional purposes. Never operate equipment with covers open.
- Do not allow bystanders in the area when operating, attaching, removing, assembling, or servicing equipment.
- Do not allow anyone to stand between tractor and unit when backing up to unit.
- Never go underneath equipment (lowered to the ground or raised) unless it is properly blocked and secured. Never place any part of the body underneath equipment or between moveable parts even when the engine has been turned off. Hydraulic system leak down, hydraulic system failures, mechanical failures, or movement of control levers can cause equipment to drop or rotate unexpectedly and cause severe injury or death. Follow Operator's Manual instructions for working underneath and blocking requirements or have work done by a qualified dealer.
- Keep bystanders away from equipment.
- Do not operate or transport equipment while under the influence of alcohol or drugs.
- Operate only in daylight or good artificial light.
- Avoid contact with electrical wires.
- Keep hands, feet, hair, and clothing away from equipment while engine is running. Stay clear of all moving parts.
- Always comply with all state and local lighting and marking requirements.
- Never allow riders on power unit or attachment.
- Power unit must be equipped with ROPS or ROPS cab and seat belt. Keep seat belt securely fastened. Falling off power unit can result in death from being run over or crushed. Keep foldable ROPS systems in "locked up" position at all times.
- Always sit in power unit seat when operating controls or starting engine. Securely fasten seat belt, place transmission in neutral, engage brake, and ensure all other controls are disengaged before starting power unit engine.
- Operate tractor PTO at the RPM speed stated in "Specifications" section.
- Do not operate PTO during transport.
- Look down and to the rear and make sure area is clear before operating in reverse.
- Do not operate or transport on steep slopes.
- Do not stop, start, or change directions suddenly on slopes.
- Use extreme care and reduce ground speed on slopes and rough terrain.
- Watch for hidden hazards on the terrain during operation.
- Stop power unit and equipment immediately upon striking an obstruction. Turn off engine, remove key, inspect, and repair any damage before resuming operation.
- Never work on scalper attachment in the raised position. Lower scalpels to the ground and service each unit individually.
- Always raise scalper arms before moving in reverse.
- Always connect safety chain from equipment to towing vehicle when transporting.

(Safety Rules continued on next page)



SAFETY RULES

ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



(Safety Rules continued from previous page)

■ AVOID INJURY OR DEATH FROM POWER LINES:

- Stay away from power lines.
- Electrocutation can occur without direct contact.
- Check clearances before raising implement.
- Do not leave the operator's seat if any part of the tractor or implement contacts electric lines.

■ Before servicing, adjusting, repairing or unplugging, stop tractor engine, place all controls in neutral, set park brake, remove ignition key, and wait for all moving parts to stop.

■ Before working underneath a raised implement, read and follow all Operator's Manual instructions and safety rules. Implement must be attached to tractor. Lift cylinder locks must be installed and lift cylinders lowered against locks. Hydraulic system leak down, hydraulic system failures, or movement of control levers can cause equipment to drop unexpectedly and cause severe injury or death.

MAINTENANCE

■ Before servicing, adjusting, repairing, or unplugging, stop tractor engine, place all controls in neutral, set park brake, remove ignition key, and wait for all moving parts to stop.

■ Before working under a raised implement, read and follow all Operator's Manual instructions and safety rules. Implement must be attached to tractor. Lift cylinder locks must be installed and lift cylinders lowered against locks. Hydraulic system leak down, hydraulic system failures, or movement of control levers can cause equipment to drop unexpectedly and cause severe injury or death.

■ Service and maintenance work not covered in OWNER SERVICE must be done by a qualified dealership. Special skills, tools and safety procedures may be required. Failure to follow these instructions can result in serious injury or death.

■ Do not modify or alter or permit anyone else to modify or alter the equipment or any of its components in any way.

■ Your dealer can supply original equipment hydraulic accessories and repair parts. Substitute parts may not meet original equipment specifications and may be dangerous.

■ Always wear relatively tight and belted clothing to avoid entanglement in moving parts. Wear sturdy, rough-soled work shoes and protective equipment for eyes, hair, hands, hearing and head; and respirator or filter mask where appropriate.

■ Do not allow other people in the area when operating, attaching, removing, assembling or servicing equipment.

■ Never go underneath equipment lowered to the ground or raised, unless it is properly blocked and secured. Never place any part of the body underneath equipment or between moveable parts even when the engine has been turned off. Hydraulic system leak down, hydraulic system failures, mechanical failures or movement of control levers can cause equipment to drop or rotate unexpectedly and cause severe injury or death. Follow Operator's Manual instructions for working underneath and blocking requirements, or have work done by a qualified dealer.

■ Ensure implement is properly attached, adjusted and in good operating condition.

■ Never perform service or maintenance with engine running.

■ Make sure hydraulic hoses and cylinders are fully purged of air before operating. Keep all persons away and fill the system by raising and lowering all functions several times. Air in the system can allow components to fall unexpectedly.

■ Keep all persons away from operator control area while performing adjustments, service or maintenance.

■ Make certain all movement of implement components has stopped before approaching for service.

(Safety Rules continued on next page)



SAFETY RULES

ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



(Safety Rules continued from previous page)

- Do not handle blades with bare hands. Careless or improper handling may result in serious injury.

- Tighten all bolts, nuts and screws to torque chart specifications. Check that all cotter pins are installed securely to ensure equipment is in a safe condition before operating.

- Ensure all safety decals are installed. Replace if damaged. (See Safety Decals section for location.)

- Ensure shields and guards are properly installed and in good condition. Replace if damaged.

- Do not disconnect hydraulic lines until machine is securely blocked or placed in lowest position and system pressure is released by operating all valve control levers.

STORAGE

- Follow manual instructions for storage.



- Keep children and bystanders away from storage area.



SAFETY & INSTRUCTIONAL DECALS

ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

Replace Immediately If Damaged!




A. 500-3-0977 Caution (1-11)



B. 100-3-1367 Safety Guard



C. 500-3-0981 Rotating Flails



D. 500-3-0980 Missing Shields Warning



E. 500-3-0182 Rotating Flails



F. 506-3-0196 Rotating Driveline Warning

(Safety Decals continued on next page)



SAFETY & INSTRUCTIONAL DECALS

ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

Replace Immediately If Damaged!



G. 500-3-0979 Rotating Part Hazard



H. 200-3-4004 Amber Reflector 9 x 2



I. 200-3-4005 Red Reflector 9 x 2



J. 200-3-4034 Orange Fluorescent Reflector 9 x 2



N. 200-3-1366 Serial Number Tag




P. 500-3-1690 Do Not Walk / Stand



K. 506-3-0194 Shield Missing Danger




L. 903-17456 Driveline Safety Sign




O. 500-3-1348 Belt Tension




Q. 700-3-0519 PTO Speed Warning



S. 506-3-0195 Hydraulic Pressure Warning



R. 500-3-1696 SMV Sign



T. 506-3-0192 Manual Container Warning



M. 500-3-1149 Belt Tension

OPERATOR SIGN-OFF RECORD

Safety is a primary concern in the design and manufacture of our products. Unfortunately, our efforts to provide safe equipment can be wiped out by an operator's single careless act.

In addition to the design and configuration of equipment, hazard control and accident prevention are dependent upon the awareness, concern, judgement, and proper training of personnel involved in the operation, transport, maintenance and storage of equipment.

It has been said “The best safety device is an informed, careful operator.” We ask you to be that kind of operator.

Alloway Equipment Company follows the general safety standards specified by the American Society of Agricultural Engineers (ASAE) and the

Occupational Safety and Health Administration (OSHA).

Anyone who will be operating and/or maintaining the Beet Defoliator must read and clearly understand all Safety, Operating, and Service & Maintenance information presented in this manual.

Do not operate or allow anyone else to operate this equipment until this information has been reviewed. Review this information annually, before the season start-up. Make periodic reviews of the Safety and Operation sections a standard practice for those using any of your equipment.

Use the following Operator Sign-off Record to verify that each operator has read and understood the information in this manual and has been instructed in the safe operation of the defoliator.

[illegible]

CHECK LISTS

PRE-DELIVERY CHECK LIST

(DEALER'S RESPONSIBILITY)

Inspect the equipment thoroughly after assembly to ensure it is set up properly before delivering it to the customer.

The following check lists are a reminder of points to inspect. Check off each item as it is found satisfactory or after proper adjustment is made.

- Check that all safety decals are installed and in good condition. Replace if damaged.
- Check that shields and guards are properly installed and in good condition. Replace if damaged.
- Check that PTO shaft is properly installed.
- Properly attach implement to tractor and make all necessary adjustments.
- Check all bolts to be sure they are tight.
- Check wheel lug nuts and adjust to proper torque.
- Check that all cotter pins and safety pins are properly installed. Replace if damaged.
- Check and grease all lubrication points as identified in "Service, lubrication information."
- Check the level of gearbox fluids before delivery. Service, if required, as specified in the "Service, lubrication information."
- Check that tractor hydraulic reservoir has been serviced and that hydraulic system and all functions have been operated through full cylinder stroke to purge air from system.
- After pressurizing and operating all Defoliator functions, stop tractor and make sure there are no leaks in the hydraulic system. Follow all safety rules when checking for leaks.

DELIVERY CHECK LIST

(DEALER'S RESPONSIBILITY)

- Check that all safety decals are installed and in good condition. Replace if damaged.
- Show customer how to make adjustments and select proper PTO speed.
- Show customer how to make adjustments.
- Instruct customer how to lubricate and explain importance of lubrication.
- Point out the safety decals. Explain their meaning and the need to keep them in place and in good condition. Emphasize the increased safety hazards when instructions are not followed.
- Present Operator's Manual and request that customer and all operators read it before operating equipment. Point out the manual safety rules, explain their meanings and emphasize the increased safety hazards that exist when safety rules are not followed.
- Show customer how to make sure driveline is properly installed and that spring-activated locking pin or collar slides freely and is seated in groove on tractor PTO shaft.
- Show customer the safe, proper procedures to be used when mounting, dismounting, and storing equipment.
- Explain to customer that when equipment is transported on a road or highway, safety devices should be used to give adequate warning to operators of other vehicles.
- Explain to customer that when equipment is transported on a road or highway, a Slow Moving Vehicle (SMV) sign should be used to provide adequate warning to operators of other vehicles.
- Explain to customer that when towing on a public road to comply with all state and local lighting/ marking laws and to use a safety tow chain.
- Make customer aware of optional equipment available so that customer can make proper choices as required.
- Point out all guards and shields. Explain their importance and the safety hazards that exist when not kept in place and in good condition.

OPERATION

Safety is a primary concern in the design and manufacture of our products. Unfortunately, our efforts to provide safe equipment can be wiped out by an operator's single careless act.

In addition to the design and configuration of equipment, hazard control and accident prevention are dependent upon the awareness, concern, judgment, and proper training of personnel involved in the operation, transport, maintenance and storage of equipment.

It has been said "The best safety device is an informed, careful operator." We ask you to be that kind of operator.

The Alloway Beet Defoliator is designed to efficiently remove the foliage from sugar beets. A series of rubber or steel flails on three drums cleans the top of the beet, leaving the exposed crown.

Be familiar with the defoliator before starting.

The owner is responsible for training operators in the safe operation of the defoliator.



WARNING

- Safety instructions are important! Read all attachment and power unit manuals; follow all safety rules and safety decal information. (Replacement manuals are available from your dealer). Failure to follow instructions or safety rules can result in serious injury or death.
- Never allow children or untrained persons to operate equipment.
- Make sure shields and guards are properly installed and in good condition. Replace if damaged.
- Keep hands, feet, hair, and clothing away from equipment while engine is running. Stay clear of all moving parts.
- Keep bystanders away from equipment.
- Operate tractor PTO at the RPM speed stated in "Specifications" section.
- Before dismounting power unit or performing any service or maintenance, follow these steps: disengage power to implement, lower the hitch and all raised components to the ground, operate valve levers to release any hydraulic pressure, set parking brake, stop engine, remove key, and unfasten seat belt.



WARNING

- Keep bystanders away from equipment.
- Never allow riders on power unit or attachment.
- Do not allow bystanders in the area when operating, attaching, removing, assembling, or servicing equipment.
- Keep hands, feet, hair, and clothing away from equipment while engine is running. Stay clear of all moving parts.



CAUTION

- Always sit in tractor seat when operating controls or starting engine. Securely fasten seat belt, place transmission in neutral, engage brake, and ensure all other controls are disengaged before starting tractor engine.
- Always comply with all state and local lighting and marking requirements.
- Always wear relatively tight and belted clothing to avoid entanglement in moving parts. Wear sturdy, rough-soled work shoes and protective equipment for eyes, hair, hands, hearing, and head.


Operation Continued

PRINCIPAL COMPONENTS

The Alloway Beet Defoliator consists of three rotating drums that have steel or rubber flails. The flails remove the foliage from the plant. Rotational power to

the drums is provided from the tractor PTO through a series of belts on each side of the machine.

An optional scalper package is available on the back of the machine to cut off the top of the remaining beet.



A. Hitch
E. Belt

B. Input Driveline
F. Rotor

C. Gearbox
G. Flails

D. Stands
H. Wheels

Figure 1. Beet Defoliator Principal Components

Operation Continued

BEET DEFOLIATOR BREAK-IN

The following should be observed when operating the unit for the first time:

1. Attach PTO shaft. Remove grease zerks to gain access to the set screws for tightening on unit.

After operating for 1/2 hour or five acres

2. Check all nuts, bolts, and other fasteners Tighten to specifications in Bolt Torque Chart, page 113.
3. Check and re-torque fasteners on flail mounting brackets.
4. Tighten wheel lug nuts to specifications in Bolt Torque Chart, page 113.
5. Inspect flail condition and mobility. Replace or repair broken parts and ensure that all swing freely.
6. Check oil level in gearbox. Add oil as required.
7. Confirm that PTO driveline shield turns freely.
8. Lubricate all grease points.

After operating for 5 hours

9. Repeat steps 1 through 6 above.
10. Check tension of drive belts. Refer to Service and Maintenance section for procedure. Adjust as required.

After operating for 10 hours

11. Repeat steps 1 through 6 above.
12. Check tension of drive belts. Adjust as required.

After operating for 15 hours and 20 hours

13. Check tension of drive belts. Adjust as required.

PRE-OPERATION CHECK LIST

(OWNER'S RESPONSIBILITY)

IMPORTANT

- **This Pre-Operation Check List is provided for the operator. It is important to follow for both personal safety and maintenance of the beet defoliator.**

- Check that all safety decals are installed and in good condition. Replace if damaged.
- GENL-LUBE--Check all lubrication points and grease as instructed in Lubrication Schedule.
- Use only a tractor of adequate power and weight to pull the unit.
- Check that the unit is properly attached to the tractor. On pull-type unit, be sure there is a mechanical retainer through the drawbar pin and safety chain is installed.
- Check oil level in gearbox. Add oil as required.
- Check that the PTO driveline turns freely and that the driveline can telescope easily.
- Check tire pressure. Adjust to specified level.
- Check flails. Inspect for damage or breakage. Make sure each swings freely. Replace or repair as required.
- Check condition of all drive belts. Align as required. Replace any that are frayed or broken. Refer to Belt Replacement.
- Check condition of scalpels. Adjust or repair as required. Refer to Scalpers.
- Inspect all hydraulic lines, hoses, couplers, and fittings. Tighten, repair, or replace any leaking or damaged components.
- Close and secure all guards, doors, and covers.

Operation Continued

CHOOSING THE CORRECT EQUIPMENT

To ensure safe and reliable operation of the beet defoliator, use a tractor with the correct specifications. Use the following guidelines to select the correct tractor.

PTO

The defoliator is equipped with a PTO driveline yoke to fit a 1-3/8" 21 spline shaft on the tractor. An optional 1-3/4" 20 spline yoke is available from the factory if required. Be sure to match the yoke to your tractor shaft.

IMPORTANT

- Do not use an adapter on the tractor shaft. It will alter the drawbar dimension and can affect the strength of the shaft.




Figure 2a. PTO Driveline

DRAWBAR

The tractor drawbar must be set to provide 16" (406mm) between the end of the PTO shaft and the center of the drawbar pin.

IMPORTANT

- Do not use PTO shaft adapters. They will change the drawbar dimension and can cause driveline failures.

NOTE: Verify that no driveline interference occurs through all phases of operation (bottoming out).




Figure 2b. Drawbar Dimension

HYDRAULIC SYSTEM

The tractor hydraulic system must be capable of 8 gpm (22 lpm) at 2,500 psi (1700 kPa). Either closed-centered or open-centered system can be used. A remote outlet is required for each circuit.

Operation *Continued*

ATTACHING THE DEFOLIATOR TO THE TRACTOR

Place unit on a level, dry area free of debris and other foreign objects



WARNING

■ **Keep bystanders away from equipment.**

1. Clear the area of all bystanders.
2. Provide enough clearance to back the tractor safely into the unit.



CAUTION

■ **Do not allow anyone to stand between tractor and unit when backing up to the unit.**

3. Back slowly and align the drawbar with the hitch.
4. Stop tractor engine, place all controls in neutral, set parking brake, remove ignition key, and wait for all moving parts to stop.
5. Use ratchet on top of hitch A-frame to set height (9 row model and smaller). The operator must supply hydraulic cylinder for 12-row model.
6. On 12-row defoliator, connect hoses from hitch cylinder to tractor hydraulics to raise or lower hitch.
7. Use hardened drawbar pin with provisions for a mechanical retainer. Install a retainer, such as a Klik Pin.
8. Be sure drawbar is pinned in its center position.
9. Attach safety chain around drawbar or cage to prevent unexpected separation. Provide sufficient slack for turning.
10. Connect PTO driveline to implement.
11. Inspect PTO to ensure driveline telescopes easily and shield rotates freely with no interference.
12. To attach driveline to tractor, retract locking collar. Slide yoke over shaft and push forward until the locking collar engages. Pull back on yoke to confirm yoke is locked in position.
13. Attach anchor chain on driveline shield to tractor frame.

Operation Continued

CONNECT THE HYDRAULICS

1. Use a clean cloth or paper towel to clean the couplers on the end of the hoses and the area around the couplers on the tractor.
2. Insert the male ends into the couplers on the tractor. Be sure they are locked in place.
3. Route the hoses along the hitch and secure in position with clips, tape, or plastic ties. Provide sufficient slack for turning.




Figure 3. Driveline and Hydraulics Attached



WARNING

- Keep hands and body away from pressurized lines. Use paper or cardboard, not hands or other body parts to check for leaks. Wear safety goggles. Hydraulic fluid under pressure can easily penetrate skin and will cause serious injury or death.
- Make sure all hydraulic hoses, fittings, and valves are in good condition and not leaking before starting power unit or using equipment. Check and route hoses carefully to prevent damage. Hoses must not be twisted, bent sharply, kinked, frayed, pinched, or come into contact with any moving parts. Operate moveable components through full operational range to check clearances. Replace any damaged hoses immediately.

COMPLETE ATTACHMENT

1. Use ratchet or hydraulic cylinder on the hitch to lower the hitch and transfer the weight to the drawbar. See Figure 4.
2. Unpin the front frame stands. Raise the stands and pin them in their stowed positions. See Figure 5.

REMOVING THE DEFOLIATOR FROM THE TRACTOR

Reverse the above procedure when unhooking from the tractor.



Figure 4. Hitch Cylinder



Figure 5. Parking Stand

Operation *Continued*

MACHINE SETTINGS

The machine can give its best performance only if it is properly set to work in the existing conditions. It may be necessary to change the machine settings during the working day if the machine is moved to a new field, or the operating conditions change.

Review this section to be familiar with the adjustments available to match the machine to the working conditions.

MACHINE LEVELING

The frame must be set level when working in the field to be sure that the flails contact the plants evenly at any place under the frame. Set when the machine is on firm, level ground. Use a tape to measure the distance between the frame and the ground, or place a level on top of the frame.

1. Use the ratchet or hydraulic cylinder on the hitch (Figure 4) to level the frame in the direction of travel.
2. Turn the adjustment crank on the rear wheels (Figure 7) to level the machine from side to side. Loosen the “U” bolt on the wheel strut, turn the crank and re-tighten the bolt.



Figure 6. Hitch Cylinder



Figure 7. Rear Wheels

(Machine Settings continued on next page)

Operation Continued

(Machine Settings continued from previous page)

FLAIL HEIGHT

Best results are obtained when the flails contact the sugar beets approximately 1/2 inch (12 mm) below the crown. This will allow the flails to remove the foliage from the beets during a pass.

Set the height of the flails by changing the height of the machine from the ground. Machine height is set with the ratchet or hydraulic cylinder on the hitch and the height of the rear wheels.

IMPORTANT

- **Maintain a level machine at all times.**

In soft or wet conditions, the tires will sink into the soil and the machine should be raised to maintain the flail contact line of 1/2 inch (12 mm) below the crown.

In crop conditions where the beet crown extends above the ground and can be knocked over, the flails can be set so that they just contact the crown.

Do not allow the flails to contact the ground. They will pick up dirt, sticks, stones and other material that can be thrown out and cause injury. This will also cause rapid wear or breakage.




Figure 8. Flail Height



Figure 9. Machine Height

FLAIL SPACING

Set flail position on the drum to follow beet rows exactly and to clean the low foliage from both sides of the crown. Change spacing of flail sets by loosening the clamping bolts on the head, and sliding the entire assembly to its new position on the rotor




Figure 10. Flail Assembly

(Machine Settings continued on next page)

Operation Continued

(Machine Settings continued from previous page)

WHEEL SPACING

The rear wheels must be set to track directly between rows. Any other positions can lead to beet contact and damage or knocking the beet out of the ground.

Change wheel assembly position by jacking up the machine, loosening top mounting bolts (Figure 11), and sliding the assembly to its desired position. Re-tighten the bolts and remove jacks.



Figure 11. Wheel Mounting Bolts

STABILIZER WHEEL POSITION

Stabilizer wheels are located on front corners of the 12 row machine (Figure 12). They must be set to the correct height to prevent dipping, thus preventing machine and plant damage.



Figure 12a. Stabilizer Wheel Mounting Position

Operation *Continued*

SCALPER SETTINGS (Optional)

Three types of scalpers are available:

- Knife (Figure 14)
- Circular (parallel arms) - (not shown; refer to Parallel Arm Rotary Scalper)
- Circular (arms) - (not shown, refer to Rotary Scalper Long Arm)

Scalpers cut the top of the crown and are positioned on the back of the machine.

The shoe, ahead of the cutting surface, must be set at the proper angle. This will allow sufficient space for the knives to cut the green portion of the beets without tipping them over.

IMPORTANT

- **Severe equipment damage may occur if attempting to go in reverse with the scalper arms down. Always raise scalper arms before going in reverse.**



Figure 14. Knife Scalpers

FIELD OPERATION

The Alloway beet defoliator is designed with the flexibility to operate well in almost any kind of crop and terrain conditions. However, the operator is responsible for being familiar with all operating and safety procedures and following them.

Each operator should review this Field Operation

section at the start of the season and as often as required to be familiar with the unit.

Operators should also review the Pre-Operation Check List, Attaching the Defoliator to the Tractor, and Transporting the Unit.



WARNING

- Operators must be instructed in and be capable of the safe operation of the equipment, its attachments, and all controls. Do not allow anyone to operate this equipment without proper instructions.
- Always comply with all state and local lighting and marking requirements.
- Always wear relatively tight and belted clothing to avoid entanglement in moving parts. Wear sturdy, rough-soled work shoes and protective equipment for eyes, hair, hands, hearing, and head.
- Do not allow bystanders in the area when operating, attaching, removing, assembling, or servicing equipment.
- Never allow riders on power unit or attachment.
- Before dismounting power unit or performing any service or maintenance, follow these steps: disengage power to implement, lower the 3-point hitch and all raised components to the ground, operate valve levers to release any hydraulic pressure, set parking brake, stop engine, remove key, and unfasten seat belt.
- Keep hands, feet, hair, and clothing away from equipment while engine is running. Stay clear of all moving parts.
- Make sure shields and guards are properly installed and in good condition. Replace if damaged.
- Never allow children or untrained persons to operate equipment.



WARNING

- Safety instructions are important! Read all attachment and power unit manuals; follow all safety rules and safety decal information. (Replacement manuals are available from dealer. Failure to follow instructions or safety rules can result in serious injury or death.
- Keep hands, feet, hair, and clothing away from equipment while engine is running. Stay clear of all moving parts.
- Inspect and clear area of stones, branches, or other hard objects that might be thrown, causing injury or damage.
- Operate tractor PTO at the RPM speed stated in "Specifications" section.



CAUTION

- Always sit in tractor seat when operating controls or starting engine. Securely fasten seat belt, place transmission in neutral, engage brake, and ensure all other controls are disengaged before starting tractor engine.

Field Operation *Continued*

TRANSPORTING THE UNIT



WARNING

■ **Never allow riders on power unit or attachment.**



CAUTION

■ **Always comply with all state and local lighting and marking requirements.**

1. Be sure all bystanders are clear of the unit.
2. Be sure center cutter is disengaged and has stopped turning (if so equipped).
3. Be sure the unit is securely attached to the tractor and all retainer pins are installed.
4. Be sure safety chain is installed on pull-type model.
5. Raise the machine.
6. Clean the SMV emblem, lights, and reflectors and be sure they are working.
7. Be sure you are in compliance with all applicable lighting and marking regulations when transporting. Check with your local authorities.
8. Never transport the unit faster than 20 mph (32 km/h). The ratio of the tractor weight to the defoliator weight plays an important role in defining acceptable travel speed. Table 1 summarizes the recommended travel speed-to-weight ratio.

Table 1: Speed vs. Weight Ratio

Road Speed	Fully equipped or loaded implement(s) weight relative to towing machine weight
Up to 32 km/h (20 mph)	1 to 1 or less
Up to 16 km/h (10 mph)	2 to 1 or less
Do not tow	more than 2 to 1

PREPARING FOR OPERATION

1. Attach the machine to the tractor
2. Lubricate the machine.
3. Review and follow the pre-operation checklist. See Pre-Operation Check List.
4. Review Transporting the Unit, before transporting to the field.
5. Pull into the field and line up with the first set of rows.
6. Determine the machine parameters that require setting before starting use. See Machine Settings.
7. Close and secure all guards, covers and access doors.

STARTING THE MACHINE

1. Start the tractor engine and run at low idle.
2. Slowly engage the tractor PTO.

IMPORTANT

■ **Engage and disengage the PTO at low idle engine RPM to minimize shock loads to the drive train.**

3. Slowly increase engine speed to the rated PTO speed of 1000 RPM.
4. Put the tractor in gear and proceed down the field.

STOPPING THE MACHINE

1. Take the tractor out of gear.
2. Slowly decrease engine speed down to the idle RPM.
3. Slowly disengage PTO clutch.

IMPORTANT

■ **Disengage clutch slowly. On newer tractors the PTO brake will stop the shaft in less than one revolution and create shock loads in the drive train if the clutch is not disengaged slowly.**

4. Stop engine and set park brake before dismounting.

Field Operation *Continued*

GROUND SPEED

The defoliator works well at 3 to 6 mph (5 to 10 Km/h) depending on density of foliage and type of job. The operator is responsible for checking condition of beets and setting speed required for best defoliating. For best results:

1. Increase speed if beet tops are completely cleaned of foliage.
2. Increase speed or raise flails if beets are being pulled out of the ground.
3. Decrease speed or lower flails if foliage is left on crown or sides.

FLAIL PATTERNS

When delivered from the factory, the flail patterns are set as shown in Figure 15. Maintain this pattern at all times.

Do not allow the flails to hit the ground where they might pick up dirt, sticks, stones and other debris that can be thrown out and cause injury. This will also cause rapid wear or breakage.









Figure 15. Standard Flail Contour

30" ROWS



22" - 26" ROWS



Field Operation *Continued*

OPERATING THE DEFOLIATOR

1. Operate the machine at its rated speed of 1000 rpm at all times. Effective removing of beet tops depends on the flail tip speed. A slower speed can result in foliage being left on the beets.
2. Operate the machine at rated speed at the end of the row until the last drum has passed over the beets.
3. When turning at the end of the field, it may be necessary to skip a machine width of rows before turning back into the field. This will depend on the width of the machine, the width of the headland, and the turning radius of the tractor.
4. Although the driveline may be equipped with an optional constant velocity (CV) joint, turning angles are limited. (See Figure 16.) Do not exceed the working angles. Turn off the machine when making sharp turns.
5. When starting a new field, or when operating conditions change:
 - a. Travel 50 feet into the field.
 - b. Shut off the tractor, place all controls in neutral, set the parking brake, remove the key, and wait for all moving parts to stop.
 - c. Go behind the machine and inspect the beets.
 - d. Check the flail spacing, wheel spacing, machine height, and scalper setting (if so equipped.)
 - e. Adjust as needed.

TURNING

The front universal is equipped with a constant velocity (CV) joint to allow for turning. Although the CV joint allows for sharper turns than a regular driveline, it does have some limitations. Refer to Figure 16.

CV joint angle should not exceed 80 degrees in either operating or standstill condition of the driveline. Larger angles will damage the joint.

The angle should never exceed 35 degrees when the driveline is under full load.

IMPORTANT

- Disengage PTO when making sharp turns.




Figure 16. Driveline Angles

HAZARD AREA



WARNING

- Make certain all movement of implement components has stopped before approaching for service.

Stay away from front, side and rear of unit while it is running. Flails can pick up stones, sticks, wire or other debris and throw it out with enough force to severely injure bystanders.

Keep out of shaded area shown in Figure 17.

Shut down unit and wait for moving parts to stop before approaching.




Figure 17. Hazard Area
PN : 500-5-0024 (2019)

ADDITIONAL EQUIPMENT (Optional)

REAR STEER

1. Mount rear steer components to back of defoliator body. Refer to Rear Steer Components, and Rear Steer Plumbing Components, in the parts section for hardware and assembly instructions.

2. Attach the sight gauge on defoliator and the hose clamp to adjustable bar. Be sure the sight gauge and hose clamp are aligned when wheels are straight.

	12R22 W/ 22" STRUTS
8R22 W/ 22" & 44" STRUTS	12R22 W/ 44" STRUTS

Additional Equipment *Continued*

STEERING VALVE

STABILIZER STRUTS

1. Mount stabilizer struts to the front of defoliator. Refer to Stabilizer Wheel Components, in the parts section, for assembly.
2. Adjust up and down so the parallel linkage is low in the front in operating position. See Figure 19. This allows maximum upward travel when operating. Pin #10 limits the downward travel of the wheel for road transport. This may be left installed when operating.




Figure 19a. Stabilizer Strut

STEEL FLAIL UNITS

This is not a field adjustment, but rather a seasonal adjustment.

Set the front drum in either the upper or lower position that best accommodates the variety of sugar beet you are defoliating. The machine is shipped from the factory with the drum in the upper (normal) position. This setting has the steel flail tips 4" higher than the rubber flail tips. The lower setting would put the steel flails only 2" higher than the rubber flails.




Figure 19b. Steel Flail Adjustment

Additional Equipment *Continued*

DOOR OPENER

The Door Opener is designed to make door opening quick and safe.

To Open Doors :

1. Move lever in tractor cab to raise doors.
2. Insert pin to lock doors in open position.

To Close Doors :

1. Remove lock pin.
2. Move lever in tractor cab to lower doors.

IMPORTANT

- **Always make sure valve is in neutral position when not controlling door opener, to prevent doors from lifting while defoliating.**



Figure 20a. Doors Closed



Figure 20b. Doors Opened


Additional Equipment *Continued*

RECOMMENDED SCALPER LOCATIONS


(Depending on Additional Equipment)

1. Measure and mark locations as shown below for desired scalper arrangement.

2. Mount Scalper Arms on back of defoliator body by sliding on rear tube of body and securing with 3/4 x 8-1/2 bolts.



12 ROW 22" SPACING



8 ROW 22" SPACING

STORAGE



WARNING

- **Keep children and bystanders away from storage area.**

IMPORTANT

- **Store in a dry, level area. Support the base with planks if required.**

After the season's use, inspect all major components of the defoliator. Repair or replace any worn or damaged components to prevent unnecessary downtime at the start of next season.

To assure a long, trouble-free life, follow this procedure when preparing the unit for storage:

1. Open all access doors and canvas covers. Be sure the door locks are in place and secured.



WARNING

- **Equipment may be pictured with covers open for instructional purposes. Never operate equipment with covers open.**

2. Thoroughly wash the machine using a pressure washer to remove all dirt, mud, debris and residue.
3. Inspect the flails, flail assemblies and drums for damage or entangled material. Repair or replace damaged parts. Remove all entangled material.
4. Inspect all hydraulic hoses, hardlines, couplers and fittings. Tighten any loose fittings. Replace any hose that is badly cut, nicked, abraded, or is separating from the crimped end of a fitting.
5. Inspect drive belts. Replace any that are damaged. Adjust to specified tension as needed.
6. Lubricate all grease fittings. Ensure that all grease cavities have been filled with grease to force out residual water from washing.
7. Touch up paint nicks and scratches to prevent rusting.
8. Close and secure access doors and canvas covers.
9. Move to storage area.

10. Select an area that is dry, level and free of debris.

11. Unhook from tractor (see Removing the Defoliator from the Tractor, page 15).

12. Lower the scalpers to the ground for storage.

13. Store the machine in an area away from human activity.

14. Do not allow children to play on or around the stored machine.



Figure 21. Open Covers



Figure 22. Scalper Storage

SERVICE & MAINTENANCE



WARNING

- Keep children and bystanders away from storage area.
- Operators must be instructed in and be capable of the safe operation of the equipment, its attachments, and all controls. Do not allow anyone to operate this equipment without proper instructions.
- Equipment may be pictured with covers open for instructional purposes. Never operate equipment with covers open.
- Keep all persons away from operator control area while performing adjustments, service, or maintenance.
- Ensure that shields and guards are properly installed and in good condition. Replace if damaged.
- Never go underneath equipment (lowered to the ground or raised) unless it is properly blocked and secured. Never place any part of the body underneath equipment or between moveable parts even when the engine has been turned off.

Hydraulic system leak down, hydraulic system failures, mechanical failures, or movement of control levers can cause equipment to drop or rotate unexpectedly and cause severe injury or death. Follow Operator's Manual instructions for working underneath and blocking requirements or have work done by a qualified dealer.

■ Do not handle blades with bare hands. Careless or improper handling may result in serious injury.

■ Before servicing, adjusting, repairing or unplugging, stop tractor engine, place all controls in neutral, set park brake, remove ignition key, and wait for all moving parts to stop.



CAUTION

■ Always wear relatively tight and belted clothing to avoid entanglement in moving parts. Wear sturdy, rough-soled work shoes and protective equipment for eyes, hair, hands, hearing, and head; and respirator or filter mask where appropriate.

■ Make certain all movement of equipment components has stopped before approaching for service.

LUBRICANTS

Use the Lubrication Service Record (Page 36), to keep a record of all scheduled maintenance.

1. Grease

Use and SAE multi-purpose high temperature grease with extreme pressure (EP) performance. A SAE multi-purpose lithium-based grease is also acceptable.

2. Gearbox Oil

Use an SAE 85W90 gear oil for all operating conditions. Capacity: 2-1/2 U.S. quarts (2.13 liters).

3. Storing Lubricants

Your unit can operate at top efficiency only if clean lubricants are used. Use clean containers to handle all lubricants. Store them in an area protected from dust, moisture, and other contaminants.

GREASING

Use the Lubrication Service Record (Page 31), to keep a record of all scheduled maintenance.

1. Use a hand-held grease gun for all greasing.

2. Wipe grease fitting with a clean cloth before greasing to avoid injecting dirt and grit.

3. Replace or repair broken fittings immediately.

4. If fittings will not take grease, remove and clean thoroughly. Also clean lubricant passageway. Replace fitting if necessary.

Service & Maintenance *Continued*

LUBRICATION SCHEDULE


The period recommended is based on normal operating conditions. Severe or unusual conditions may require more frequent lubrication or oil changes. Refer to Figure 24 for details.

DAILY OR EVERY 10 HOURS

1. Lubricate PTO driveline, position A, Figure 22 and Figure 24.
2. Use dipstick to check gearbox oil level.

EVERY 20 HOURS

1. Lubricate bearing zerk with one shot of grease at each B position (13 positions). See Figure 25.
2. Lubricate couplers with 10 shots of grease at each C position.



For PTO installation, remove grease zerks to gain access to the set screws for locking PTO onto gearbox.



Figure 23. Dipstick




Figure 22. Driveline




Figure 24a. Lubrication Diagram



Figure 24b. Position E Detail

Service & Maintenance *Continued*

If you remove the flail tube from 9 - 12 row defoliators, thoroughly clean both halves of drive couplers and apply new grease to all gear teeth. Remove grease zerk C when replacing flail tube to allow air to purge from coupler assembly. Replace grease zerk and follow lubrication schedule.

EVERY 40 HOURS

1. Lubricate PTO driveline (1 location).
2. Lubricate scalper pivot bearings (4 locations each scalper).

ANNUALLY

1. Change gearbox oil (twice annually in very dusty or dirty conditions).
2. At start and end of season, lubricate scalper and hitch screw jacks (1 location each screw jack).
3. At start and end of season, lubricate trailing wheel pivots - position E (1 location each pivot).

CHANGING GEARBOX OIL

Although the oil in the gearbox never wears out, dust, dirt and moisture can enter through the breather when oil heats up and cools down during operation. These contaminants must be removed on a regular basis to ensure long life of working components.

To change oil, follow this procedure:

1. Shut off tractor, place all controls in neutral, set parking brake, remove key and wait for all moving parts to stop.
2. Clear area of all bystanders.
3. Place a pan under drain plug. Remove drain, fill and level plugs.
4. Allow the gearbox to drain for 10 minutes.
NOTE: It is best to drain oil when gearbox is hot to remove the most contaminants. Use a stiff probe to clean breather hole in fill plug.
5. Install and tighten drain plug.
6. Dispose of used oil in an approved container.
7. Add 1 quart of SAE 85W90 gear oil through fill



Figure 25. Position B Detail



Figure 26. Scalper Pivot Bearings




Figure 27. Gearbox, Fill & Drain Plugs plug. Check level, using dipstick.

8. Install and tighten the level and fill plugs

Service & Maintenance *Continued*

Lubrication Service Record

NOTE: See prior pages for details.
Copy this page to continue service record.

✓ = CHECK
L = LUBRICATE

C = CHANGE
R = REPACK

[illegible]

Service & Maintenance *Continued*

WHEEL SPACING

Rear wheels are designed to move along frame to align with rows. To adjust spacing of wheels, follow this procedure:

1. Shut off tractor, place all controls in neutral, set parking brake, remove key, and wait for all moving parts to stop.
2. Clear the area of all bystanders.
3. Use a jack with sufficient capacity to lift frame. Place planks under jack for extra support if required.
4. Measure from the centerline of the machine to determine the required spacing. Mark position on frame.
5. Lift frame until wheels have cleared the ground.
6. Loosen wheel assembly mounting bolts.
7. Slide assembly along frame to desired position.



Figure 28. Wheel Mounting Bolts

8. Tighten mounting bolts to specifications in Bolt Torque Chart, page 113.
9. Lower frame and remove jack.

FLAIL SPACING

Flails are mounted to an assembly or head that clamps to the rotating drum. To adjust head position, follow this procedure:

1. Shut off tractor, place all controls in neutral, set parking brake, remove key, and wait for all moving parts to stop.
2. Clear the area of all bystanders.
3. Disconnect driveline from the tractor.
4. Open canvas covers.
5. Measure from center line of machine to determine required spacing.
6. Loosen assembly clamping nuts.



CAUTION

■ Equipment may be pictured with covers open for instructional purposes. Never operate equipment with covers open.



Figure 29. Rubber Flails

7. Slide or tap assembly to desired position
8. Tighten clamping bolts to specifications in Bolt Torque Chart, page 113.
9. Repeat with other head assemblies as required.
10. Close and secure canvas covers.
11. Attach driveline to tractor.

Service & Maintenance *Continued*

FLAIL REPLACEMENT

The flails swing on pins through the head. When replacing damaged or broken flails, follow this procedure:

1. Shut off tractor, place all controls in neutral, set parking brake, remove key, and wait for all moving parts to stop.
2. Clear the area of all bystanders.
3. Disconnect driveline from tractor.
4. Open canvas covers.
5. Remove the mounting bolt and cotter pin.
6. Slide pin out to release flail.
7. Replace with new flail. Be sure to assemble the spacers and bushings in their appropriate positions. See Parts Section and Flail Patterns.
8. Re-install bolt and cotter pin. Tighten bolt per specifications in Bolt Torque Chart, page 113.
9. Repeat with other flails as required.



CAUTION

■ Equipment may be pictured with covers open for instructional purposes. Never operate equipment with covers open.

10. Remove 5/8 locknut.
11. Tap out 5/8 x 3 1/2 carriage bolt.
12. Remove flails and bushing.
13. Install new bushing and flail.
14. Install bolt and nut.
15. Tighten bolt and nut.
16. Close and secure access doors and covers and install secure guards before resuming work.
17. Attach driveline to tractor.



Figure 30. Steel Flails



Figure 31. Flail Assembly




Figure 32. Steel Flails

Service & Maintenance *Continued*

BELT TENSION

Drive belts transmit power to turn drums and flails. Belt tension must be maintained to insure proper machine performance. Overtightening will cause belts and pulleys to run hot; loose belts will allow slipping. Either condition will cause rapid wear and failure.

When machine is new, or after installing new belts, tension should be checked and adjusted as required every 4 to 5 hours for 2 to 3 days - until belts have "run in."

To check belt tension, follow this procedure:

1. Shut off tractor, place all controls in neutral, set parking brake, remove key, and wait for all moving parts to stop.
2. Clear the area of all bystanders.
3. Disconnect driveline from tractor.
4. Open belt access doors and fasten prop rods.
5. Align sight gauge with spring washer as shown in Figure 33 to set proper belt tension. Do not over-tighten.
6. Close and secure access doors and covers and install secure guards before resuming work.
7. Attach driveline to tractor.

BEARING LOCK COLLARS

Bearings are held on shafts by locking collars. Always install locking collars to lock by rotating in the direction of shaft rotation.




Figure 33. Belt Tension Gauge




Figure 34. Locking Collar

Service & Maintenance *Continued*

BELT REPLACEMENT

Belts must be maintained in good condition at the proper tension to obtain expected performance. Replace frayed or separated belts. Do not use belt dressings at any time. Keeping the belts at the required tension will prevent slippage.

To replace belts, follow this procedure:

1. Shut off tractor, place all controls in neutral, set parking brake, remove key, and wait for all moving parts to stop.
2. Clear the area of all bystanders.
3. Disconnect driveline from tractor.
4. Open the belt access doors.
5. Loosen the bolts on the belt tensioner arm.

6. Remove belt.

7. Install new belt. Do not force belt over pulley and damage the cords.

IMPORTANT

Use only genuine Alloway replacement parts

8. Tension the belt. See Belt Tension, page 34.
9. Check that all pulleys are aligned.
10. Check the tension of the new belt every 4 to 5 hours the first 2 or 3 days of operation. Adjust as required.
11. Close and secure access doors and covers and install secure guards before resuming work.
12. Attach driveline to the tractor.

FLAIL TUBE HANGER BEARING

Flail tube hanger bearings on 6 row, 9 row, and 12 row: 30" steel machines require annual maintenance (lubrication) and inspection.

Follow this procedure:

1. Shut off tractor, place all controls in neutral set parking brake, remove key, and wait for all moving parts to stop.
2. Clear the area of all bystanders.
3. A rolling floor jack is required to slide the flail tube away from the bearing hanger plate for annual greasing and inspection.
4. Locate the bearing. The hanger bearing is located on the tail shaft flail tube (tube without a drive sheath attached).
5. Support center hanger plate with floor jack.
6. Remove the four 5/8 x 1 -1/2 carriage bolts from the tail shaft bearing plate and 3/4 hanger plate bolt.
7. Lower and move back until tubes can be separated.
8. Remove the bearing protector lock/collar.




Figure 35. Hanger Bearings

9. Wipe the bearing clean and inspect the grease seal.
10. Lubricate bearing zerk with 3 to 4 shots of grease.
11. Slide tube back onto coupler and re-attach tail shaft bearing.
12. Repeat for all three hanger bearings.

NOTE: Do not lubricate new bearings.

Service & Maintenance *Continued*

SCALPERS

Scalpers must be set for each crop and operating condition. The scalper should be set to cut off only the green portion of beet.

Set the shoe angle:

- a. Loosen bolts (1) and (2), Figures 36a & 36b..
- b. Move shoe to desired angle.
- c. Tighten bolts to torque values specified in Bolt Torque Chart page 113.

KNIFE SCALPER

To adjust knife scalper, follow this procedure:

1. Set cutting edge of the knife at the lowest portion of the assembly to prevent skipping over the beets.
2. Set knife height and angle:
 - a. Loosen bolts (3) and (4), Figures 36a & 36b.
 - b. Move knife to desired height and angle.
 - c. Tighten bolts to torque values specified in Bolt Torque Chart page 113.
3. Down pressure position:
 - a. Increase spring tension to decrease skipping (5).
 - b. Decrease spring tension if scalper pulls beets out of ground.
4. Float position:
 - a. Increase spring tension for less pressure on shoe (5).
 - b. Decrease spring tension for more pressure on shoe.




Figure 36a. Knife Scalper (Down Pressure)




Figure 36b. Knife Scalper (Float)

CIRCULAR SCALPER

To adjust circular scalper, follow this procedure:

1. Set angle of assembly so cutting edge of disc is the lowest portion of scalper. This will prevent skipping over beets.

IMPORTANT

Shoe angle "A" should be set as small as possible without pushing beets over.

2. Set disc height:
 - a. Move disc assembly to desired height.
 - b. Tighten bolts (1), (2) and (3) to torque values specified in Bolt Torque Chart page 113.

IMPORTANT

Do not set disc to run on or below ground level.

3. Use spring bolt to set spring tension (5).
 - a. Increase tension to minimize skipping.
 - b. Decrease tension if disc pulls beet over.

TROUBLE SHOOTING

The Alloway Beet Defoliator uses rubber or steel flails on drums to remove foliage from the tops of sugar beets. It is a simple and reliable system that requires minimal maintenance. The following table lists problems, causes, and solutions that you may

encounter. If you encounter a problem that is difficult to solve even after reading through this table, please call your local Alloway dealer. When calling, please have this manual and your unit's serial number ready.

PROBLEM	CAUSE	SOLUTION
Drums won't turn	Tractor PTO not operating	Repair tractor PTO
	Broken cross shaft or drive coupler on central hanger bearing	Replace (9 or 12 row units only)
Belt wears rapidly	Machine plugged	Remove accumulated debris
	Pulleys out of alignment	Align pulleys
	Loose or overtightened belts	Adjust belt tension
	Overloaded/Running too low	Raise unit or reduce travel speed
Flails break	Machine too low	Raise machine
	Hitting rocks or other debris	Clean field more thoroughly before planting
Tires don't turn	Mud buildup	Adjust tire pressure to 15-20 psi
Beet crown not clean	Machine too high	Lower the machine
	Flails broken	Replace broken flails
	Traveling too fast	Slow down
	Engine speed too slow	Increase speed to rated PTO RPM
	Scalper required	Install and set scalper
	Scalper bounces	Increase scalper spring tension
Beets pulled out of ground	Machine too low	Raise machine
	Traveling too slowly	Increase ground speed
	Scalper too low	Raise scalper
Defoliator vibrates	Driveline doesn't telescope	Remove, disassemble, clean and lubricate telescoping joint
	Flail tube out of balance	Confirm all flails are in place Balance tube if required

TROUBLE SHOOTING

This Troubleshooting section applies specifically to Rear Steering system of the defoliator.


Please contact your dealer's service department if you encounter a malfunction not addressed in this section.

PROBLEM	CAUSE	SOLUTION
Steering valve does not respond when activated	Steering Valve not connected to Power Beyond output Coupler checking flow between tractor and valve Faulty hydraulic couplers	Connect Steering Valve to Power Beyond output Inspect quick coupler on tractor and defoliator Identify and replace faulty coupler
Weak, slow steering operation	Load sensing signal not present. Test by creating deadhead situation to force high pressure standby. Pressure Reducing Valve flow obstructed by debris Tractor hydraulic oil level low	Identify and remove load signal blockage between tractor and steering valve Remove and clean valve 6 Add hydraulic oil to tractor's reservoir
	Tractor hydraulic system has insufficient pressure	Inspect hydraulic system and repair or replace components causing problem
	Tractor load sensing responds with inadequate pressure	Inspect load sensing circuit components to identify problem
Will not maintain neutral steering	Directional Valve not closing because of contamination	Remove and clean valve 5A and/or 5B.
Excessive hydraulic noise	Steering valve connected directly to SCV	Connect Steering Valve to Power Beyond output
Hydraulic system overheating	Row Centering Valve relief valve pressure setting too low	Set relief valve pressure higher

RIGID BEET DEFOLIATOR

Frame Components	44 - 45
Frame Drive Components.....	46 - 47
Belt Drive Components	48 - 51
Belt Cover Components	52 - 55
Flail Tube Components.....	56 - 57
Knife/Flail Components.....	58 - 63
Top Cover Components	64 - 65
Rear Strut Components	66 - 77
Scalper Components	78 - 79
Scalper Toolbar Components	80 - 81
Stabilizer Wheel Components	82 - 83
Hub & Spindle Components	84 - 85
Row Finder Components	86 - 89
Row Finder Parallel Link Mount Components	90 - 99
Rear Steer Hydraulic Components	100
Row Finder Hydraulic Components	101
Scalper Hydraulic Components	102
Door Opener Hydraulic Components	103
Hydraulic Strut Components	104-107
Hardline Components	108 - 109
PTO Drive Shaft Components	110 - 114
Gear Box Components	115
Light Kit Components	116 - 117
Hitch Components	118 - 121
Hitch Hydraulic Components	122


FRAME COMPONENTS



FRAME COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1505	FRONT DOOR	2
2	500-2-1506	DOOR FRAME WELDMENT LH- S SERIES	2
3	500-2-1635	1222 S-SERIES BODY WELDMENT- 2016	1
4	500-2-1689	S-SERIES HARDLINE GUARD WELD	1
5	500-3-0969	REAR FLAP 622 AND 1222	4
6	500-3-1142	ROD, FLAP-1222	2
7	500-3-2697	REAR CROSS CHANNEL - 1222	2
8	500-3-2701	REAR CROSS CHANNEL 1222 (RIGHT)	2
9	500-3-4643	S SERIES TOP STRAP #1	4
10	500-3-4647	SHROUD MOUNT COVER	4
11	500-3-4781	S SERIES TOP STRAP #2	4
12	500-3-4782	S SERIES TOP STRAP #3	4
13	500-3-4783	S SERIES TOP STRAP #4	2
14	500-3-4784	S SERIES TOP STRAP #5	2
15	500-3-4785	S SERIES TOP RUBBER	3
16	505-3-0868	FLAP SHIELD 3-1/2"	5
17	505-3-1089	FLAP SHIELD 12"	18
18	505-3-1097	FLAP SHIELD 6"	4
19	500-2-0531	PARKING STAND	2
20	900-25004	1/8 HAIR PIN CLIP	2
21	500-3-0279	PIN	2
	500-2-1636	1222 S SERIES FLAIL ASSEMBLY - 2016	
	500-2-1637	1222 S SERIES TOPPER 2016	


FRAME DRIVE COMPONENTS



FRAME DRIVE COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	100-3-1367	DECAL - SAFETY GUARD DO NOT REMOVE	1
2	100-3-3331	KEY - 1/2 X 1/2 X 3	6
3	100-3-3333	KEY - 3/8 X 3/8 X 2	2
4	120-3-0192	KEY 3/8 X 3/8 X 3	1
5	500-2-0537	SHIELD WITH DECAL	2
6	500-2-1526	DRIVE SHIELD WELDMENT	2
7	500-3-1662	KEY - 1/2 X 2-1/2 SQUARE	2
8	500-3-2778	GEARBOX MOUNT PLATE	1
9	500-3-4708	CROSS SHAFT - 1222 S SERIES	4
10	500-3-4845	GEARBOX FLATBAR MOUNT #2	2
11	500-3-5090	TUBE, SHIELD 59 12R22 2016"	2
12	500-3-5091	TUBE, SHIELD 42 12R22 2016"	2
13	900-01221	BOLT HEX 1/2" X 1"	6
14	900-01225	1/2 NC X 1-1/2 HEX BOLT GR 5	28
15	900-01229	1/2-13 X 2 HEX BOLT GRD 5	1
16	900-06009	NUT HEX 1/2 UNC	28
17	900-06143	1/2 NC SPIRALOCK NUT ZP GR5	20
18	900-06270	3/8" JAM NUT	4
19	900-11035	1/2 FLAT WASHER	36
20	900-16255	3/8 NC X 3/4 SOCKET HEAD SET SCREW CUP	4
21	901-01142	PILLOW BLOCK BEARING 2"	2
22	903-17525	CROSS KIT - WSLR #44R	1
23	903-17639	YOKE HALF 44 SERIES - 1.75" B	1
24	903-17710	YOKE HALF 44 SERIES - 2.00" B	1
25	903-18479	R600 GEARBOX W/ 1-3/4"	1
26	905-15001	1/8 PTF STR GRS FTNG	2
	500-2-1637	S-SERIES TOPPER 2019	


BELT DRIVE COMPONENTS - RH



BELT DRIVE COMPONENTS - RH

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-0777	WELD PULLEY	2
2	100-3-3331	KEY - 1/2 X 1/2 X 3	4
3	500-2-1383	PIVOT ARM WELD	1
4	500-2-1520	PIVOT ARM WELD LH	2
5	500-3-0990	PLASTIC SHIELD	3
6	500-3-1059	TYPE E HUB - 1-15/16	1
7	500-3-1060	HUB 2" TYPE "E" W/KW	1
8	500-3-1201	BEARING PLATE FRONT	1
9	500-3-1202	BEARING PLATE REAR	1
10	500-3-1246	SPECIAL WASHER	12
11	500-3-1248	8" OD FLAT PULLY	1
12	500-3-1653	BEARING PLATE 2" 630 & 1222	1
13	500-3-4724	BEARING PLATE FRONT	1
14	900-01225	BOLT HEX 1/2 X 1 1/2 GR 5	4
15	900-01339	HEX BOLT 5/8 NC X 1 1/4 GD 5 ZP	1
16	900-01345	BOLT, HH, 5/8-11 X 2, GR5 ZP	20
17	900-01363	HEX BOLT 5/8 NC X 4 1/2 GD 5 ZP	3
18	900-01367	SCREW, CAP 5/8 X 5-1/2 UNC	3
19	900-01750	CARRIAGE BOLT 1/2 NC X 1 1/4 GD 5 ZP	4
20	900-01784	CARRIAGE BOLT 5/8 NC X 1-1/2	12
21	900-11013	WASHER, LOCK 1/2	6
22	900-06009	NUT HEX 1/2 UNC	8
23	900-06013	NUT, HH, 5/8-11, ZP	16
24	900-11015	WASHER, LOCK, 5/8, ZP	1
25	900-11035	1/2 FLAT WASHER	4
26	900-11088	WASHER, FLAT, SAE, 5/8, ZP, HTM ROLLER BED	2
27	900-16251	SOCKET HEAD SET SCREW	1
28	901-01008	BEARING - NANFS 211-32 2.00	1
29	901-01079	2.00 INSERT BRG NA-211-32	1
30	901-01282	BEARING - 1-15/16 4-BOLT (F4B-SXR-115-FF)	4
31	901-01314	FLANGE 4 HOLE 100mm PF211H	1
32	901-01315	FLANGE 4 HOLE 100mm PF211H LUBE	1
33	903-01426	BELT 5/5V950	1
34	903-01456	BELT - 6/5V2500	1
35	903-08390	PULLEY -5/5V850	1
36	903-08391	PULLEY, 5/5V1 320	1
37	903-08486	SHEAVE, 6/5V14.0	1
38	903-08488	SHEAVE, 6/5V 9.75	1
39	500-2-1521	SPRING TENSIONER WELDMENT LH	1


BELT DRIVE COMPONENTS - LH



BELT DRIVE COMPONENTS - LH

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	100-3-3331	KEY - 1/2 X 1/2 X 3	6
2	500-2-0580	SPRING SUPPORT WELD	3
3	500-2-0777	WELD PULLEY	5
4	500-2-1384	PIVOT BASE WELD - TENSIONER	2
5	500-2-1520	PIVOT ARM WELD LH	1
6	500-2-1522	SPRING TENSIONER WELDMENT RH	1
7	500-3-0990	PLASTIC SHIELD	6
8	500-3-1059	TYPE E HUB - 1-15/16	1
9	500-3-1060	HUB 2" TYPE "E" W/KW	1
10	500-3-1201	BEARING PLATE FRONT	4
11	500-3-1246	SPECIAL WASHER	6
12	500-3-1247	CLEVIS	3
13	500-3-1250	THREADED ROD	3
14	500-3-1255	SIGHT GAGE	3
15	500-3-2682	PLATE - REAR CORNER	1
16	500-3-4607	BEARING PLATE 2 630	2
17	500-3-4724	BEARING PLATE FRONT	2
18	500-3-4765	SIDE DRUM ADJUSTER PLATE	2
19	900-01225	1/2 NC X 1-1/2 HEX BOLT GR 5	28
20	900-01345	BOLT, HH, 5/8-11 X 2, GR5 ZP	32
21	900-01750	CARRIAGE BOLT 1/2 NC X 1 1/4 GD 5 ZP	8
22	900-01784	CARRIAGE BOLT 5/8 NC X 1-1/2	28
23	900-02526	BOLT HEX 1/2 X 2-3/4 GR 5	3
24	900-06009	NUT HEX 1/2 UNC	28
25	900-06013	NUT, HH, 5/8-11, ZP	60
26	900-06143	1/2 NC SPIRALOCK NUT ZP GR5	20
27	900-01349	HEX BOLT 5/8 NC X 2 1/2 GD 5 ZP	1
28	900-11013	WASHER, LOCK 1/2	3
29	900-11035	1/2 FLAT WASHER	36
30	900-11088	WASHER, FLAT, SAE, 5/8, ZP , HTM ROLLER BED	6
31	900-16251	SOCKET HEAD SET SCREW	1
32	900-01223	BOLT, HEX HEAD, 1/2 X 1-1/4"	16
33	901-01008	BEARING - NANFS 211-32 2.00	6
34	901-01282	BEARING - 1-15/16 4-BOLT (F4B-SXR-115-FF)	6
35	901-01428	2 ECCENTRIC COLLAR BEARING	2
36	905-14018	SPRING - 2.44 OD X .38 WIRE X 6.00 FL X 10.5 COILS	2
37	900-01227	BOLT HEX 1/2 X 1 3/4 GR 5 ZP	2
38	900-01367	SCREW, CAP 5/8 X 5-1/2 UNC	1
39	903-01457	BELT 6/5V1700	1
	500-2-1636	1222 S SERIES FLAIL ASSEMBLY - 2016	
	500-2-1637	1222 S SERIES TOPPER 2016	


BELT COVER COMPONENTS



BELT COVER COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	200-3-5103	3/8 HINGE (ALLEGIS - H885SS)	1
2	500-2-1626	SIDE DOOR FRAME WELDMENT LH	1
3	500-2-1629	SIDE DOOR FRAME WELDMENT RH	1
4	500-3-5057	FRONT SIDE SHIELD- LH	1
5	500-3-5058	TOP SIDE SHIELD- LH	1
6	500-3-5059	BOTTOM SIDE SHIELD- LH	1
7	500-3-5060	BACK SIDE SHIELD- LH	1
8	500-3-5061	FRONT SIDE SHIELD- RH	1
9	500-3-5063	BACK SIDE SHIELD- RH	1
10	500-3-5064	TOP SIDE SHIELD- RH	1
11	500-3-5080	REAR BOTTOM SIDE SHIELD RH	1
12	500-3-5081	FRONT BOTTOM SIDE SHIELD RH	1
13	500-3-5097	REAR S SERIES BELT BOX STIFFENER	1
14	500-3-5098	FRONT S SERIES BELT BOX STIFFENER	1
15	500-3-5109	FRONT S SERIES BELT BOX STIFFENER	1
16	500-3-5270	3/8" DOOR HINGE (SHORT)	1
17	500-3-5275	RH DOOR PANEL	1
18	500-3-5276	LH DOOR PANEL	1
19	900-01694	CARRIAGE BOLT 3/8 NC X 3/4	39
20	900-06135	WHIZ NUT - 1/4 - 20	14
	500-2-1625	S-SERIES RIGID SIDE DOOR ASSY LH	1
	500-2-1627	SIDE DOOR ASSY LH	1
	500-2-1628	S-SERIES RIGID SIDE DOOR ASSY RH 2016	1
	500-2-1630	SIDE DOOR ASSY RH	1


BELT COVER COMPONENTS - LATCH AND LIFT DETAIL



BELT COVER COMPONENTS - LATCH AND LIFT DETAIL

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1769	S-SERIES BOTTOM ROD WELDMENT	1
2	500-3-4799	S SERIES FLUSH GRAB HANDLE	1
3	500-3-5092	ANGLE- GAS SPRING	2
	500-3-5274	ANGLE- GAS SPRING	1
4	500-3-5260	DOOR OPENER-2018	1
5	500-3-5278	PLATE- GAS SPRING MOUNT	2
6	900-01001	.25 UNC X 1/2 BOLT	14
7	900-01694	CARRIAGE BOLT 3/8 NC X 3/4	39
8	900-06135	WHIZ NUT - 1/4 - 20	14
9	900-06137	WHIZ NUT - 5/16 NC	6
10	900-06139	3/8 NC FLANGED WHIZ NUT	38
11	905-06022	ROTARY LATCH- ALLEGIS PART #1-300 ZN RH	1
12	905-06026	BALL STUD, GAS SPRING 10 STROKE"	6
13	905-06028	GAS SPRING, 10 STROKE	2
	500-2-1625	S-SERIES RIGID SIDE DOOR ASSY LH	
	500-2-1628	S-SERIES RIGID SIDE DOOR ASSY RH 2016	




FLAIL TUBE COMPONENTS



FLAIL TUBE COMPONENTS


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-0779	FLAIL TUBE 1222 DRIVE	1
2	500-2-0780	FLAIL TUBE 1222 DRIVEN	1
3	500-2-0556	SMOOTH FLAIL TUBE, DRIVE (1222)	2
4	500-2-0555	SMOOTH FLAIL TUBE, DRIVEN (1222)	2
5	500-2-0633	CENTER BEARING PLATE	3
6	500-3-0785	CENTER SHAFT	3
7	500-3-0865	SHORT SHAFT	1
8	500-3-0863	LONG SHAFT	2
9	500-3-1060	HUB, 2" W/ KEYWAY	6
10	500-3-0345	OUTER DRIVE SLEEVE	3
11	901-09126	O-RING	6
12	900-39030	SNAP RING	6
13	901-01300	BEARING, 4-BOLT ROUND	3
14	901-01280	BEARING, INSERT 1-15/16	3
15	901-01281	BEARING PROTECTOR	3
16	500-3-0338	INNER DRIVE HUB	3
17	900-01409	BOLT, 3/4 NC x 2-3/4	-
18	900-01229	BOLT, 1/2 NC x 2	-
19	900-02526	BOLT, 1/2 NC x 2-3/4	-
20	900-03119	BOLT, 3/8 NC x 3	-
21	500-3-0779	WASHER, LOCK 3/8 (HIGH COLLAR)	-
22	900-11013	WASHER, LOCK 1/2	-
23	900-11038	WASHER, FLAT 3/4	-
24	900-06510	NUT, TOP LOCK 3/4 NC	-
25	100-3-3331	KEY, 1/2 x 1/2 x 3	6

KNIFE COMPONENTS




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	505-3-0001	L-KNIFE (SMALL HOLE)	-
2	500-3-1735	L-KNIFE (LARGE HOLE)	-
3	505-3-0004	STEEL CUP KNIFE, SHORT 7"	(2008 - PRESENT)
4	505-3-0972	STEEL CUP KNIFE, SHORT 6-3/16"	(PAST - 2007)
5	500-3-2134	SPACER, SMALL HOLE	-
6	500-3-1736	SPACER, LARGE HOLE	-
7	500-3-1733	BUSHING	-
8	505-3-0405	BUSHING, WEAR	-
9	900-03064	BOLT, CARRIAGE 5/8 NC X 3-3/4, GR8 ZP (PARTIAL THREAD)	-
10	900-01792	BOLT, CARRIAGE 5/8 NC X 3-1/2, GR5 ZP (PARTIAL THREAD)	-
11	900-11037	WASHER, FLAT 5/8	-
12	900-06508	NUT, TOP LOCK 5/8 NC, GR8	-
13	900-06145	NUT, SPIRALOCK FLANGE 5/8 NC, GR8	-

FLAIL COMPONENTS 8-BOLT





ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-3-5249	PLATE-FLAIL MOUNT HEX HEAD STOP	3
2	500-3-2578	RUBBER FLAIL 12" TAPERED 62B BF12T NOFFSINGER	22
3	500-2-1757	PLATE, FLAIL MOUNTING BRACKET - 8 PIN	1
4	900-11033	FLAT WASHER 3/8 ZP	3
5	500-2-1475	FLAIL BRACKET - 8 PIN	1
6	500-3-5252	SPACER 3/8" X 2" DIA- RUBBER FLAIL	2
7	500-3-5261	SPACER 1.375" X 2" DIA- RUBBER FLAIL	4
8	900-01109	BOLT HEX 3/8UNC X 1 GR 5	3
9	900-01363	HEX BOLT 5/8 NC X 4 1/2 GD 5 ZP	4
10	900-01394	HEX BOLT- 5/8 X 14 UNC ZP	8
11	900-06013	NUT, HH, 5/8-11, ZP	4
12	900-06337	WELD NUT HEX 5/8 UNC	4
13	900-06500	NUT HEX 3/8 TOP LOCK	3
14	900-11015	WASHER, LOCK, 5/8, ZP	4
	500-2-1756	HALF RUBBER FLAIL ASSEMBLY 6-5-6-5 8-BOLT	2
	500-2-1758	FULL RUBBER FLAIL ASSEMBLY 8-BOLT	

FLAIL COMPONENTS 6-BOLT





ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-0067	FLAIL MTG BRACKET WELD	1
2	500-2-1755	FLAIL MTG BRACKET WELD 6 BOLT	1
3	500-3-2578	RUBBER FLAIL 12" TAPERED 62B BF12T NOFFSINGER	16
4	500-3-5249	PLATE-FLAIL MOUNT HEX HEAD STOP	3
5	500-3-5252	SPACER 3/8" X 2" DIA- RUBBER FLAIL	2
6	500-3-5261	SPACER 1.375" X 2" DIA- RUBBER FLAIL	4
7	900-01109	BOLT HEX 3/8UNC X 1 GR 5	3
8	900-01394	HEX BOLT- 5/8 X 14 UNC ZP	3
9	900-06500	NUT HEX 3/8 TOP LOCK	3
10	900-11033	FLAT WASHER 3/8 ZP	3
11	900-01363	HEX BOLT 5/8 NC X 4 1/2 GD 5 ZP	4
12	900-06013	NUT, HH, 5/8-11, ZP	4
13	900-11015	WASHER, LOCK, 5/8, ZP	4
	500-2-1752	HALF RUBBER FLAIL ASSEMBLY 6-5-6 (6 BOLT)	
	500-2-1753	HALF RUBBER FLAIL ASSEMBLY 5-6-5 (6 BOLT)	
	500-2-1754	FULL RUBBER FLAIL ASSEMBLY- 6 BOLT	

FLAIL COMPONENTS (8-PIN)



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-0067	FLAIL BRACKET - 8 PIN	2
2	500-2-0068	RUBBER FLAIL PIN WELDMENT	4
3	500-3-0316	RUBBER FLAIL	22
4	500-3-0151	SPACER 1" RUBBER FLAIL	4
5	900-01105	3/8-16 X .75" HEX BOLT	4
6	900-06500	NUT HEX 3/8 TOP LOCK	4
7	900-23041	3/16 X 1 COTTER PIN	4
	500-2-1476	FLAIL ASSEMBLY - 8 PIN - 6,5,6,5	



FLAIL COMPONENTS (10-PIN)



FLAIL COMPONENTS (10-PIN)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1583	RUBBER FLAIL PIN WELDMENT- 10 PIN	5
2	500-2-1581	FLAIL MTG BRACKET WELD- 10 PIN	2
3	500-3-0151	SPACER 1" RUBBER FLAIL	14
4	500-3-2578	RUBBER FLAIL 12" TAPERED 62B BF12T NOFFSINGER	28
5	900-01105	3/8-16 X .75" HEX BOLT	5
6	900-06500	NUT HEX 3/8 TOP LOCK	5
7	900-23041	3/16 X 1 COTTER PIN	5
	500-2-1580	RUBBER 10 PIN FLAIL ASSEMBLY 5-6-5	
	500-2-1582	RUBBER 10 PIN FLAIL ASSEMBLY 6-5-6	


CYLINDER ASSEMBLY



CYLINDER ASSEMBLY

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1323	CYLINDER SUPPORT ARM WELD - TOP COVER	1
2	500-2-1512	BOTTOM CYLINDER PLATE WELDMENT	1
3	500-3-2696	SPACER - SLIDE	4
4	500-3-2698	HOLD DOWN PLATE - TOP COVERS	2
5	500-3-2699	UPPER CYLINDER PIN - HYD DOORS	1
6	500-3-4668	DOOR LIFT ARMS #2	2
7	500-3-4674	DOOR LIFT ARMS #1	2
8	500-3-4703	CYLINDER ARM SPACER	2
9	500-3-4882	S SERIES CYLINDER PULL PLATE	2
10	900-01345	BOLT, HH, 5/8-11 X 2, GR5 ZP	4
11	900-01407	3/4-10 X 2-1/2 HEX BOLT ZP	2
12	900-01422	BOLT HEX 3/4 X 5	2
13	900-06015	NUT, HH, 3/4-10, ZP	2
14	900-06508	NUT HEX 5/8 UNC TOP LOCK	4
15	900-06510	3/4 NUT, HEX TOP LOCK	2
16	900-11017	WASHER, LOCK, 3/4, ZP	2
17	900-11037	WASHER, FLAT, 5/8"	8
18	900-11038	3/4" FLAT WASHER	6
19	905-21453	STANDARD HYDRAULIC CYL 2 X 12	1
20	900-01225	1/2 NC X 1-1/2 HEX BOLT GR 5	
21	900-11035	1/2 FLAT WASHER	
22	900-06143	1/2 NC SPIRALOCK NUT ZP GR5	
	500-2-1504	CYLINDER ASSY	


REAR STRUT - SINGLE LARGE TIRE COMPONENTS



REAR STRUT - SINGLE LARGE TIRE COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	700-2-0168	TRACTION TIRE ASSY (RH)	1
	905-09130	- TIRE, 12.4 X 24	
	905-09127	- RIM, 24 x 10 x 8 BOLT	
	700-2-0167	TRACTION TIRE ASSY (LH)	
	905-09130	- TIRE, 12.4 X 24	
	905-09127	- RIM, 24 x 10 x 8 BOLT	
2	700-2-0165	HUB & SPINDLE ASSY	1
3	500-2-0993	SINGLE REAR STRUT (RH)	1
	500-2-1065	SINGLE REAR STRUT (LH)	
4	500-2-1495	MOUNTING ANGLE - EXTENDED	1
5	500-3-2259	WHEEL SCRAPER (12.4 x 24 TIRE)	1
6	500-3-1328	PIVOT PIN	1
7	500-3-1151	BUSHING	2
8	900-01437	BOLT, 3/4 NC x 8-1/2	4
9	900-03463	EYE BOLT, 3/4 NC x 6	4
10	900-01369	BOLT, 5/8 NC X 6	2
11	900-06013	NUT, 5/8 NC	2
12	900-11015	WASHER, LOCK, 5/8	2
13	900-06015	NUT, 3/4 NC	8
14	900-11017	WASHER, LOCK, 3/4	8
15	900-23084	PIN, COTTER, 3/8 X 3-1/2	1
16	900-01241	BOLT, 1/2 NC x 3-1/2	1
17	900-06504	NUT, TOP LOCK, 1/2 NC	1
18	905-15024	GREASE ZERK, 1/4-28 UNF STRAIGHT	1
	500-2-1030	REAR STRUT ASSEMBLY - SINGLE LH	
	500-2-0996	REAR STRUT ASSEMBLY - SINGLE RH	


REAR STRUT - DUAL LARGE TIRE COMPONENTS



REAR STRUT - DUAL LARGE TIRE COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	700-2-0167	TRACTION TIRE ASSY (RH)	1
	905-09130	- TIRE, 12.4 X 24	
	905-09127	- RIM, 24 x 10 x 8 BOLT	
2	700-2-0168	TRACTION TIRE ASSY (LH)	1
	905-09130	- TIRE, 12.4 X 24	
	905-09127	- RIM, 24 x 10 x 8 BOLT	
3	700-2-0165	HUB & SPINDLE ASSY	2
4	500-2-0998	DUAL REAR STRUT (22")	1
	500-2-1023	DUAL REAR STRUT (30")	
5	500-2-1495	MOUNTING ANGLE - EXTENDED	1
6	500-3-2259	WHEEL SCRAPER (12.4 x 24 TIRE)	2
7	500-3-1328	PIVOT PIN	1
8	500-3-1151	BUSHING	2
9	900-03463	EYE BOLT, 3/4 NC x 6	4
10	900-01437	BOLT, 3/4 NC x 8-1/2	4
11	900-01373	BOLT, 5/8 NC x 7	2
12	900-01245	BOLT, 1/2 NC x 4	2
13	900-06504	NUT, TOP LOCK, 1/2 NC	2
14	900-06013	NUT, 5/8 NC	2
15	900-06015	NUT, 3/4 NC	8
16	900-11017	WASHER, LOCK, 3/4	8
17	900-11015	WASHER, LOCK, 5/8	2
18	900-23084	PIN, COTTER, 3/8 X 3-1/2	1
19	905-15024	GREASE ZERK, 1/4-28 UNF STRAIGHT	1
	500-2-0997	REAR STRUT ASSY - DUAL (22")	
	500-2-1025	REAR STRUT ASSY - DUAL (30")	


REAR STRUT - DUAL LARGE TIRE (PIVOT) COMPONENTS



REAR STRUT - DUAL LARGE TIRE (PIVOT) COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	700-2-0167	TRACTION TIRE ASSY (RH)	1
	905-09130	- TIRE, 12.4 X 24	
	905-09127	- RIM, 24 x 10 x 8 BOLT	
2	700-2-0168	TRACTION TIRE ASSY (LH)	1
	905-09130	- TIRE, 12.4 X 24	
	905-09127	- RIM, 24 x 10 x 8 BOLT	
3	700-2-0165	HUB & SPINDLE ASSY	2
4	500-2-1151	SPINDLE HOLDER (44")	1
	500-2-1042	SPINDLE HOLDER (30")	
5	500-2-1071	REAR DUAL PIVOT STRUT	1
6	500-2-1046	WELD, REAR STRUT, MOUNTING ANGLE	1
7	500-3-2236	PIVOT BUSHING	1
8	500-3-1151	BUSHING	4
9	500-3-2270	CYLINDER PIN	1
10	500-3-1328	PIVOT PIN	1
11	900-03463	EYE BOLT, 3/4 NC x 6	4
12	900-01437	BOLT, 3/4 NC x 8-1/2	4
13	900-03061	BOLT, 1 NF x 7-1/2 GR8	1
14	900-01245	BOLT, 1/2 NC x 4	2
15	900-06504	NUT, TOP LOCK, 1/2 NC	2
16	900-06515	NUT, TOP LOCK, 1 NF	1
17	900-06015	NUT, 3/4 NC	8
18	900-11017	WASHER, LOCK, 3/4	8
19	900-11040	WASHER, 1	2
20	900-23084	PIN, COTTER, 3/8 X 3-1/2	1
21	900-25007	HITCH PIN, 3/16	2
22	905-15024	GREASE ZERK, 1/4-28 UNF STRAIGHT	2
	500-2-1044	REAR STRUT ASSEMBLY - DUAL 30" PIVOT	


REAR STEER - DUAL LARGE TIRE (PIVOT) COMPONENTS



REAR STEER - DUAL LARGE TIRE (PIVOT) COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	700-2-0167	TRACTION TIRE ASSY (RH)	2
	905-09130	- TIRE, 12.4 X 24	
	905-09127	- RIM, 24 x 10 x 8 BOLT	
2	700-2-0168	TRACTION TIRE ASSY (LH)	2
	905-09130	- TIRE, 12.4 X 24	
	905-09127	- RIM, 24 x 10 x 8 BOLT	
3	700-2-0165	HUB & SPINDLE ASSY	4
4	500-2-1042	SPINDLE HOLDER (30")	2
	500-2-1151	SPINDLE HOLDER (44")	
5	500-2-1153	LOWER STRUT	2
6	500-2-2448	LOWER PIVOT (W/ EAR)	1
7	500-2-1220	LOWER PIVOT (W/O EAR)	1
8	500-2-1209	UPPER STRUT (W/ EAR)	1
9	500-2-1219	UPPER STRUT (W/O EAR)	1
10	905-21452	CYLINDER 1-1/4 x 2-1/2 x 4	1
11	500-2-0828	PIN	2
12	500-2-1200	TIE ROD (66" SPACING)	1
	500-2-1205	TIE ROD (88" - 154" SPACING)	
13	903-05031	PIVOT LINK (RH)	1
14	903-05030	PIVOT LINK (LH)	1
15	500-3-1151	BUSHING	4
16	200-3-4081	BUSHING	4
17	901-01145	BUSHING (OILITE)	2
18	900-01541	BOLT, 1 NC x 7-1/2	2
19	900-06288	JAM NUT, 1-1/8 NC (RH)	1
20	900-06310	JAM NUT, 1-1/8 NC (LH)	1
21	900-01429	BOLT, 3/4 NC x 6-1/2	8
22	900-03462	EYE BOLT, 3/4 NC x 8	8
23	500-3-2517	PRESSURE PLATE	2


REAR STEER - DUAL LARGE TIRE (STEERABLE) COMPONENTS



REAR STEER - DUAL LARGE TIRE (STEERABLE) COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	900-06015	NUT, HH, 3/4-10, ZP	18
2	901-01145	- THRUST BEARING	2
3	900-01345	- BOLT, HH, 5/8-11 X 2, GR5 ZP	6
4	900-31068	COVER PLATE	2
5	905-15024	- ZERK 1/4-28 UNF STRAIGHT	4
6	900-11015	- WASHER, LOCK, 5/8, ZP	6
7	900-11037	WASHER, FLAT, 5/8"	2
8	500-3-2519	WEAR PLATE - UHMW	2
9	500-2-1358	PIN WELD	1
10	900-01417	HEX BOLT-3/4NC X 3.75 GR5 ZP	1
11	900-11017	WASHER, LOCK, 3/4, ZP	18
12	500-2-1205	ADJUSTMENT TUBE ASSY - REAR STEER	1
13	900-01429	HEX BOLT - 3/4NC X 6-1/2 GR5 ZP	8
14	900-03462	EYE BOLT 3/4 X 8	8
15	900-31069	CLAMP BODY - HOSE HOLDER	4
16	905-21452	DOUBLE CYLINDER - 1.50 X 2.5 X 4 STROKE PER SIDE	1
17	900-02356	BOLT, HH 5/16 X 1-3/4, GR5 ZP	2
18	905-21400	HYD CYL - 3.5 X 8	2
19	500-2-1459	STRUT LOWER PIVOT - REAR STEER (2013)	1
20	500-2-1460	STRUT LOWER PIVOT - REAR STEER WO/EAR (2013)	1
21	500-2-1470	STRUT UPPER WELD - REAR STEER (DRIVE)	1
22	500-2-1471	RIGID REAR STEER ADJUSTMENT WELD	1
23	500-2-1446	ADJUSTABLE REAR STEER EYE BOLT	1
24	900-06019	1-8 HEX NUT	2
25	905-09068	WASHER, 1 SAE	2
26	900-11035	1/2 FLAT WASHER	4
27	900-06504	NUT, LOCK, TOP, 1/2-13, GR C ZP	4
28	500-2-1461	PRESSURE PAD WELD	2
29	900-01419	3/4-10 X 4 HEX BOLT	1
30	500-3-3034	HEIGHT GAUGE INDICATOR	1
31	500-3-3028	SIGHT GAUGE BRACKET	1
32	500-3-3029	SIGHT GAUGE INDICATOR	1
33	900-11033	FLAT WASHER 3/8 ZP	3
34	902-15116	DECAL, STEERING INDICATOR	1
35	900-01113	3/8NC X 1-1/2 HEX BOLT GR 5	1
36	900-06500	NUT HEX 3/8 TOP LOCK	1
37	900-11013	WASHER, LOCK 1/2	2
38	900-06009	NUT HEX 1/2 UNC	4
39	900-06013	NUT, HH, 5/8-11, ZP	4
40	500-2-1360	STRUT UPPER WELD -(REAR STEER) WO/EAR	1
41	900-01225	1/2 NC X 1-1/2 HEX BOLT GR 5	2
42	500-2-1469	PIN WELD	1
	500-1-0398	2 PAIR LARGE TIRES - STEERABLE PIVOT STRUTS	


REAR STEER - OFFSET DUAL LARGE TIRE (STEERABLE) COMPONENTS



REAR STEER - OFFSET DUAL LARGE TIRE (STEERABLE) COMPONENTS


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1229	- VERTICAL PIVOT - REAR STRUT ASSY	1
2	500-2-1444	- FUD ADJUSTABLE REAR STEER STRUT WELD	1
3	500-2-1445	ADJUSTABLE REAR STEER ARM (FUD)	1
4	500-2-1446	ADJUSTABLE REAR STEER EYE BOLT	1
5	500-2-1484	- STEERING GAUGE WELD (FUD)	1
6	500-2-1779	- TANDEM 44" SPINDLE HOLDER LH - STEERABLE FUD	1
7	500-2-1781	TANDEM 44" SPINDLE HOLDER RH - STEERABLE FUD	1
8	500-3-2236	BUSHING - WHEEL STRUT (PIVOT)	1
9	500-2-1203	ADJUSTMENT TUBE WELD - REAR STEER	1
10	500-2-1204	OUTER ADJUSTMENT TUBE - REAR STEER	1
11	500-3-5297	BOLT HOLD- REAR STEER	1
12	700-3-0143	SPINDLE REAR STRUT	1
13	905-21452	DOUBLE CYLINDER - 1.50 X 2.5 X 4 STROKE PER SIDE	1
14	900-01227	BOLT HEX ½ X 1 ¾ GR 5 ZP	7
15	900-01237	BOLT HEX ½-13 X 3	2
16	900-01241	BOLT, HH, 1/2-13 x 3-1/2, GR5 ZP	2
17	900-01345	BOLT, HH, 5/8-11 X 2, GR5 ZP	1
18	900-01357	SCREW, CAP 5/8 X 3-½ UNC	2
19	900-01417	HEX BOLT-3/4NC X 3.75 GR5 ZP	2
20	900-01429	HEX BOLT - 3/4NC X 6-1/2 GR5 ZP	4
21	900-01529	BOLT, HH 1 NC X 4-1/2 GR5 ZP (FULL THREAD)	1
22	900-01541	HEX BOLT - 1NC X 7-1/2 GR5 ZP	1
23	900-06009	NUT HEX 1/2 UNC	7
24	900-06015	NUT, HH, 3/4-10, ZP	2
25	900-06019	1-8 HEX NUT	3
26	900-06060	SLOTTED HEX NUT 7/8 -14 NF	1
27	900-06310	1-1/8 NC JAM LEFT HAND ZP	1
28	900-06504	NUT, LOCK, TOP, 1/2-13, GR C ZP	2
29	900-06514	NUT, LOCK, 1 NC	1
30	900-11013	WASHER, LOCK 1/2	7
31	900-11015	WASHER, LOCK, 5/8, ZP	2
32	900-11017	WASHER, LOCK, 3/4, ZP	8
33	900-11021	LOCK WASHER - 1	1
34	900-11035	1/2 FLAT WASHER	3
35	900-23064	COTTER PIN - 1/4 X 2	1
36	901-01146	BRONZE BUSHING 1.5 ID X 2.0 OD X 2 LONG	1
37	901-01152	BEARING CUP (TIMKEN #25520)	1
38	901-01324	BEARING CUP (TIMKEN #25821)	1
39	901-09215	GREASE SEAL	1
40	902-15117	DECAL, STEERING INDICATOR (FUD)	1
41	903-05030	UNIBALL 3/4" X 1-1/8 NC LH	1
42	905-09039	WHEEL BOLT 9/16-18 X 1-11/16	8
43	905-09067	WASHER, 7/8 SAE"	1
44	905-09068	WASHER, 1 SAE	2
45	905-09130	TIRE 12.4-24	1
46	905-09135	HUB CAP	1
47	905-09182	HUB ONLY"	1
48	905-15024	ZERK 1/4-28 UNF STRAIGHT	3
49	905-09127	RIM 24 X 10, 88T	1
	500-2-1778	TANDEM 44" PIVOT REAR STEER STRUT ASSY LH - FUD	

CIRCULAR KNIFE SCALPER - STRAIGHT ARM




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1438	MOUNT WELD (RH)	1
2	500-3-2948	MOUNT (LH)	1
3	500-2-1318	PIVOT TUBE WELD	1
4	500-2-1068	SCALPER SHOE	1
5	500-2-0072	LIFT ROD	1
6	500-3-0172	RETAINING COLLAR	1
7	900-16063	SET SCREW, 1/2 N x 1-1/4	1
8	500-3-0157	SPRING	1
9	500-3-1756	SPRING RETAINER	1
10	500-3-1757	LIFT ROD CLAMP	2
11	500-3-1561	MOUNT SPACER	2
12	900-11037	WASHER, 5/8	2
13	900-35026	U-BOLT, 5/8 NC x 3 x 4-1/2	2
14	500-3-2507	SHOE LINK BAR	2
15	500-3-2265	SHOE ADJUSTMENT ARM	2
16	500-3-1556	DISC SPACER	2
17	500-3-1557	DISC ADJUSTMENT ARM	1
18	500-2-1138	DISC MOUNT	1
19	905-09178	ROTARY DISC HUB	1
20	500-3-1940	DISC COVER	1
21	500-3-1582	ROTARY DISC	1

STRAIGHT KNIFE SCALPER - PARALLEL ARM




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	900-11017	WASHER LOCK 3/4 ZP	2
2	900-11033	WASHER FLAT 3/8 ZP	1
3	900-11035	WASHER FLAT 1/2	2
4	900-11038	WASHER FLAT 3/4	1
5	900-06145	NUT WHIZ 5/8-11 NC	4
6	900-06510	3/4 NUT, HEX TOP LOCK	4
7	900-11013	WASHER LOCK 1/2	4
8	900-11015	WASHER LOCK 5/8 ZP	1
9	500-3-0675	EYE BOLT, 3.8 x 8	1
10	500-3-0910	KNIFE SCALPER	1
11	500-3-0991	LINKAGE ARM (LH)	1
12	500-3-0992	LINKAGE ARM (RH)	1
13	900-01245	BOLT HH 1/2-13 NC X 4 GRD 5 ZP	2
14	500-2-0518	"H" LINKAGE ARM	1
15	900-06005	NUT HEX 3/8	2
16	900-06009	NUT HEX 1/2-13 NC	3
17	900-06013	NUT HEX 5/8-11 NC ZP	1
18	900-06015	NUT HEX 3/4-10 NC ZP	2
19	200-3-2631	PIN	4
20	500-2-0338	LOWER SHOE MOUNT	1
21	500-3-0201	ECCENTRIC SPACER	1
22	500-3-0635	A-BOLT, 3/4 NC x 4 x 4	1
23	500-2-0335	SHOE (LH)	1
	500-2-0336	SHOE (RH)	1
24	400-3-0263	EXTENSION SPRING	1
25	500-2-0330	UPPER MOUNT	1
	500-2-0999	KNIFE SCALPER ASSEMBLY LH W/PARALLEL LINK	
	500-2-1000	KNIFE SCALPER ASSEMBLY RH W/PARALLEL LINK	

SCALPER TOOLBAR COMPONENTS - PARALLEL ARM




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1437	OUTER SETBACK ARM WELDMENT (LARGE TIRES)	-
2	500-2-1436	INNER SETBACK ARM WELDMENT (LARGE TIRES)	-
3	905-21400	HYDRAULIC CYLINDER - 3.5 X 8	-
	905-21380	- SEAL KIT (PRINCE CYLINDERS ONLY)	-
	905-21401	- SEAL KIT (MONARCK CYLINDERS ONLY)	-
4	500-2-0941	SCALPER MOUNT INNER	-
5	500-2-0942	SCALPER MOUNT OUTER	-
6	500-2-0684	1-1/4" PIN WELDMENT	-
7	500-3-3019	SCALPER TUBE - (1222)	2
	500-3-2183	SCALPER TUBE - (630, 822)	1
8	900-01223	1/2 NC X 1-1/2 HEX BOLT GR5	-
9	900-01437	3/4 NC X 8-1/2 HEX BOLT GR5	-
10	900-03463	3/4-10 EYE BOLT	-
11	500-3-0635	3/4-10 X 4 A BOLT	-
12	900-06015	HEX NUT - 3/4 NC	-
13	900-06143	1/2 NC SPIRALOCK NUT GR5 ZP	-
14	900-11017	LOCK WASHER, 3/4	-
15	900-11038	WASHER, 3/4	-
16	900-11035	WASHER, 1/2	-
17	900-02356	BOLT, 5/16 NC X 1-3/4 GR5 ZP	-
18	900-31068	COVER PLATE AND BOLT	-
19	900-31069	CLAMP BODY	-
	500-1-0154	SCALPER TOOLBAR W/PARALLEL LINK- (822)	-
	500-1-0156	SCALPER TOOLBAR W/PARALLEL LINK- (1222)	-

SCALPER TOOLBAR COMPONENTS - STRAIGHT ARM




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1437	OUTER SETBACK ARM WELDMENT (LARGE TIRES)	-
	500-2-1040	OUTER SETBACK ARM WELDMENT (SMALL TIRES)	-
2	500-2-1436	INNER SETBACK ARM WELDMENT (LARGE TIRES)	-
	500-2-1041	INNER SETBACK ARM WELDMENT (SMALL TIRES)	-
3	905-21400	HYDRAULIC CYLINDER - 3.5 X 8	-
	905-21380	- SEAL KIT (PRINCE CYLINDERS ONLY)	-
	905-21401	- SEAL KIT (MONARCK CYLINDERS ONLY)	-
4	500-2-1439	SCALPER MOUNT INNER	-
5	500-2-1440	SCALPER MOUNT OUTER	-
6	500-2-0684	1-1/4" PIN WELDMENT	-
7	500-3-1579	SCALPER TUBE - (1222)	2
	500-3-2182	SCALPER TUBE - (922)	1
	500-3-2181	SCALPER TUBE - (630, 822)	1
	500-3-2965	SCALPER TUBE - (430, 622)	1
8	900-01223	1/2 NC X 1-1/2 HEX BOLT GR5	-
9	900-01437	3/4 NC X 8-1/2 HEX BOLT GR5	-
10	900-03463	3/4-10 EYE BOLT	-
11	900-35026	U-BOLT, 5/8 NC X 4-1/2 LONG	-
12	900-06015	HEX NUT - 3/4 NC	-
13	900-06143	1/2 NC SPIRALOCK NUT GR5 ZP	-
14	900-06145	NUT, SPIRALOCK FLANGE 5/8 NC, GR8	-
15	900-11035	WASHER, 1/2	-
16	900-11017	LOCK WASHER, 3/4	-
17	900-02356	BOLT, 5/16 NC X 1-3/4 GR5 ZP	-
18	900-31068	COVER PLATE AND BOLT	-
19	900-31069	CLAMP BODY	-
	500-1-0152	SCALPER TOOLBAR ASSY W/STRAIGHT ARM-(12R22) W/ 22",40",44" STRUTS	-

STABILIZER WHEEL COMPONENTS



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1328	STABILIZER WHEEL ARM	1
2	200-2-0689	CASTER PIVOT	1
3	500-2-1310	LOWER MOUNT	1
4	500-2-1311	UPPER MOUNT	1
5	200-3-2621	SIDE PLATE (LH)	1
6	200-3-2622	SIDE PLATE (RH)	1
7	200-2-0928	HUB & SPINDLE ASSEMBLY	1
8	200-2-0988	MONORIB TIRE & RIM ASSEMBLY	1
9	905-23014	RATCHET JACK	1
10	700-3-2600	PIVOT PIN	1
11	500-3-1151	BRONZE BUSHING	2
12	200-3-1766	OILITE BUSHING	2
13	200-3-1233	OILITE WASHER	1
14	200-3-1219	RETAINER PLATE	1
15	200-3-4641	U-BOLT, 5/8 NC x 4 x 3-1/4	4
16	900-01221	BOLT, 1/2 NC x 1	1
17	900-01225	BOLT, 1/2 NC x 1-1/2	8
18	900-11013	WASHER, LOCK 1/2	9
19	900-06145	NUT, SPIRALOCK 5/8 NC	8
20	905-15024	GREASE ZERK, 1/4-28 UNF STRAIGHT	1
21	900-01123	BOLT, 3/8 NC, 2-3/4	1
22	900-06500	NUT, TOP LOCK, 3/8 NC	1
	500-2-1309	FRONT STABILIZER WHEEL ASSEMBLY	


STABILIZER WHEEL HUB COMPONENTS




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	905-09082	HUB W/ CUPS	1
2	901-01148	BEARING CUP	2
3	901-01149	BEARING CONE	2
4	901-09127	SEAL	2
5	200-3-1240	FORK SPINDLE	1
6	200-3-2726	SHORT NUT, 1-1/4 NC	1
7	900-06024	NUT, 1-1/4 NC	3
	200-2-0928	HUB & SPINDLE (COMPLETE KIT)	

HUB & SPINDLE ASSEMBLY COMPONENTS

700-2-0165 8-BOLT HUB ASSEMBLY




500-2-0972 5-BOLT HUB ASSEMBLY



HUB & SPINDLE ASSEMBLY COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	905-09182	HUB (8-BOLT)	1
2	905-09174	HUB (5-BOLT)	1
3	901-01324	BEARING CUP (25821)	1
4	901-01016	BEARING CUP (LM67010)	1
5	901-01152	BEARING CUP (25520)	1
6	901-01022	BEARING CUP (LM48510)	1
7	901-01326	BEARING CONE (25877)	1
8	901-01015	BEARING CONE (LM67048)	1
9	901-01325	BEARING CONE (25590)	1
10	901-01023	BEARING CONE (LM48548)	1
11	901-09215	GREASE SEAL (CR20148)	1
12	901-09002	GREASE SEAL (17273VHY-BX)	1
13	905-09067	WASHER, 7/8 SAE	1
14	900-06060	NUT, SLOTTED, 7/8 NF	1
15	900-23064	PIN, COTTER, 1/4 x 2	1
16	900-23045	PIN, COTTER, 3/16 x 2	1
17	905-09135	HUB CAP (DC17)	1
18	905-09009	HUB CAP (DC13)	1
19	700-3-0143	SPINDLE (8-BOLT)	1
20	500-3-2151	SPINDLE (5-BOLT)	1
21	905-09039	WHEEL BOLT, 9/16 NF x 1-11/16	8
22	905-09011	WHEEL NUT, 1/2 NF	5
	905-09003	HUB - 5 BOLT INCLUDES: #2, #4, #6	
	905-09136	HUB - 8 BOLT INCLUDES: #1, #3, #5	
	100-2-1051	HUB ASSEMBLY - 5 BOLT INCLUDES: #2, #4, #6, #8, #10, #12, #18	
	905-09128	HUB ASSEMBLY - 8 BOLT INCLUDES: #1, #3, #5, #7, #9, #11, #17	
	500-2-0972	HUB & SPINDLE ASSEMBLY - 5 BOLT	
	700-2-0165	HUB & SPINDLE ASSEMBLY - 8 BOLT	

ROW FINDER KIT - POWER BEYOND RIGID TOOLBAR MOUNT




500-1-0368 ROW FINDER KIT - POWER BEYOND RIGID TOOLBAR MOUNT

ROW FINDER KIT - POWER BEYOND RIGID TOOLBAR MOUNT

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1255	LOWER TUBE WELDMENT- ROW FINDER	1
2	500-2-1081	H WELD ROW FINDER	1
3	500-3-0991	PIVOT ARM, 5/8" HOLES	1
4	500-3-0992	PIVOT ARM, 3/4" HOLES	1
5	900-06145	5/8 WHIZ NUT	4
6	900-06510	3/4 NUT, HEX TOP LOCK	4
7	500-2-1254	MOUNT WELD - ROW FINDER	1
8	200-3-2631	PLATED PIN	4
9	905-21400	HYD CYL - 3.5 X 8	1
10	500-2-1029	HORIZONTAL ADJ TUBE - ROW FINDER	1
11	200-3-1445	U-BOLT 4 x 3 x 1/2	2
12	900-06143	1/2 NC SPIRALOCK NUT ZP GR5	12
13	200-3-1447	U-BOLT 1/2NC X 2 X 5.25	2
14	500-2-1248	ROW FINDER ASSY - POWER BEYOND VALVE	1
15	900-31067	WELD PLATE-HYD HOSE CLAMP SP-DS-3	0
16	900-31069	CLAMP BODY	8
17	900-31071	BOLT, STACKING 5/16 UNC	2
18	900-31068	COVER PLATE	2
19	900-02356	BOLT, HH 5/16 X 1-3/4, GR5 ZP	2
20	900-01437	BOLT, HH, 3/4-10 X 8-1/2, GR5 ZP	2
21	900-03463	BOLT, EYE, 3/4" NC X 6"	2
22	900-11017	WASHER, LOCK, 3/4, ZP	4
23	900-06015	NUT, HH, 3/4-10, ZP	4
24	900-01225	BOLT HEX 1/2 X 1 1/2 GR 5	4
	500-1-0368	ROW FINDER KIT - POWER BEYOND RIGID TOOLBAR MOUNT	


ROW FINDER KNIFE SCALPER EXTENSION COMPONENTS



ROW FINDER KNIFE SCALPER EXTENSION COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1380	ROW FINDER KNIFE SCALPER EXTENSION WELD	1
2	700-2-1279	STEERING PADDLE - SENSOR	1
3	700-3-2170	SHAFT HORIZONTAL PIVOT	1
4	500-2-1258	LRG PIVOT WELD	1
5	700-3-0383	OILITE BUSHING - FF-1618-1	4
6	900-11037	WASHER, FLAT, 5/8"	2
7	905-14007	SPRING - 1.245 OD X .148 WIRE X .4029 P X 7.75 LONG	1
8	905-14022	SPRING - 1.25 OD X .105 WIRE X 4.00 LONG X 12.5 COILS	2
9	900-06145	5/8 WHIZ NUT	4
10	900-01121	3/8NC X 2-1/2 HEX BOLT GR 5	4
11	900-06500	NUT HEX 3/8 TOP LOCK	8
12	900-06504	NUT, LOCK, TOP, 1/2-13, GR C ZP	2
13	905-15024	ZERK 1/4-28 UNF STRAIGHT	2
14	905-03262	ROW FINDER VALVE	1
15	700-2-0854	FINGER MOUNT WELD	2
16	700-3-2188	FINGER - LH	1
17	700-3-2189	FINGER - RH	1
18	700-3-2182	TUBE-DOWN PRESURE BAR (PAINTED)	1
19	700-2-0853	SPRING TENSIONER WELD	1
20	700-2-0856	THREADED ROD - ROW FINDER	1
21	700-3-2185	COMPRESSION SPRING RETAINER	4
22	900-01245	1/2 X 4 HEX BOLT GR5 ZP	2
23	900-03465	EYE BOLT 5/8 X 3	1
24	700-3-2183	BUSHING - DOWN PRESSURE SPRING	1
25	700-3-2187	INSIDE WASHER - EYEBOLT	1
26	900-06013	NUT, HH, 5/8-11, ZP	2
27	900-11015	WASHER, LOCK, 5/8, ZP	1
28	900-01223	BOLT, HEX HEAD, 1/2" X 1-1/4", GR5, ZP	4
29	900-06143	1/2 NC SPIRALOCK NUT ZP GR5	4
30	900-01117	3/8 NC X 2 HEX BOLT GR 5	3
31	900-01013	HEX BOLT 1/4 NC X 1 1/2 GD5 ZP	1
32	900-06496	1/4-20 TOP LOCK HEX NUT	2
33	903-05044	EYEBOLT - ROD END	1
34	900-06006	NUT, HEX HEAD 3/8 NF, ZP	2
35	900-01113	3/8NC X 1-1/2 HEX BOLT GR 5	1
36	700-3-2343	ADJUSTMENT PLATE - ROW FINDER	1
37	901-01323	SET COLLAR - 1.38	1
38	900-03112	1/4-20 X 2 1/4 HEX HEAD GR8ZP	1
39	500-3-2705	PLATE - DROP PLATE	1
40	900-01001	.25 UNC X 1/2 BOLT	1
41	900-11009	1/4 SPRING LOCK WASHER ZP	1
42	500-3-2704	ROW FINDER TOP COVER	1
43	900-01009	1/4-20 X 1 ZP HEX BOLT	2
44	900-06001	1/4-20 HEX NUT	2
45	900-11031	1/4 FLAT WASHER	2
	500-2-1379	ROW FINDER KNIFE SCALPER EXTENSION ASSY	


TOOLBAR ROW FINDER COMPONENTS



TOOLBAR ROW FINDER COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1168	PIVOT MOUNT	1
2	700-2-0851	BOTTOM PIVOT	1
3	700-3-2170	PIVOT SHAFT	1
4	700-3-0383	BUSHING (OILITE)	4
5	700-3-2182	LOCK COLLAR	1
6	700-2-0853	SPRING TENSIONER	1
7	700-2-0854	FINGER MOUNT	2
8	700-3-2188	FINGER (LH)	1
9	700-3-2189	FINGER (RH)	1
10	700-2-0856	TENSIONER ROD	1
11	905-14007	TENSIONER SPRING	1
12	700-3-2187	INSIDE WASHER	1
13	700-3-2183	BUSHING (TENSIONER)	1
14	900-03465	EYE BOLT	1
15	700-2-0850	STEERING PADDLE	1
16	500-3-1578	U-BOLT, 1/2NC x 3 x 4	2
17	500-3-0635	A-BOLT, 3/4NC x 4 x 4	2
18	903-05044	ROD END EYE BOLT	1
19	700-3-2343	ADJUSTMENT PLATE	1
20	905-03262	CONTROL VALVE	1
21	900-01245	BOLT, 1/2 NC x 4	2
22	700-3-2185	SPRING RETAINER	4
23	905-14022	SPRING	2
24	500-3-2548	ADAPTER MOUNT	2
25	700-2-0908	TOP COVER	1
	500-2-1169	ROW FINDER COMPLETE ASSEMBLY	


STRAIGHT ARM SCALPER ROW FINDER COMPONENTS



STRAIGHT ARM SCALPER ROW FINDER COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1259	PIVOT MOUNT	1
2	500-2-1258	BOTTOM PIVOT	1
3	700-3-2170	PIVOT SHAFT	1
4	700-3-0383	BUSHING (OILITE)	4
5	700-3-2182	LOCK COLLAR	1
6	700-2-0853	SPRING TENSIONER	1
7	700-2-0854	FINGER MOUNT	2
8	700-3-2188	FINGER (LH)	1
9	700-3-2189	FINGER (RH)	1
10	900-03465	EYE BOLT	1
11	700-3-2187	INSIDE WASHER	1
12	700-3-2183	BUSHING (TENSIONER)	1
13	700-2-0856	TENSIONER ROD	1
14	905-14007	TENSIONER SPRING	1
15	901-01323	LOCK COLLAR, 1-3/8"	1
16	700-2-0850	STEERING PADDLE	1
17	903-05044	ROD END EYE BOLT	1
18	700-3-2343	ADJUSTMENT PLATE	1
19	905-03262	CONTROL VALVE	1
20	900-01245	BOLT, 1/2 NC x 4	2
21	700-3-2185	SPRING RETAINER	4
22	905-14022	SPRING	2
23	500-2-1269	ROP COVER	1
	500-2-1257	ROW FINDER COMPLETE ASSEMBLY	


PARALLEL LINK SCALPER ROW FINDER COMPONENTS



PARALLEL LINK SCALPER ROW FINDER COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1380	PARALLEL LINK PIVOT MOUNT	1
2	500-2-1258	BOTTOM PIVOT	1
3	500-2-1378	PARALLEL LINK MOUNT	1
4	500-2-0518	"H" LINKAGE ARM	1
5	500-3-0991	LINKAGE ARM (LH)	1
6	500-3-0992	LINKAGE ARM (RH)	1
7	500-2-0338	LOWER SHOE MOUNT	1
8	500-2-0335	SHOE (LH)	1
	500-2-0336	SHOE (RH)	
9	500-3-0910	KNIFE SCALPER	1
10	500-3-0201	ECCENTRIC SPACER	1
11	700-3-2188	SHORT FINGER (LH)	1
	500-3-2934	EXTENDED FINGER (LH)	
	500-3-2937	LONG FINGER (LH)	
12	700-3-2189	SHORT FINGER (RH)	1
	500-3-2933	EXTENDED FINGER (RH)	
	500-3-2936	LONG FINGER (RH)	
13	700-2-0854	FINGER MOUNT	2
14	700-2-0853	SPRING TENSIONER	1
15	700-3-2182	LOCK COLLAR	1
16	700-3-0383	OILITE BUSHING	4
17	700-3-2170	PIVOT SHAFT	1
18	700-2-0856	TENSIONER ROD	1
19	905-14007	TENSIONER SPRING	1
20	900-03465	EYE BOLT	1
21	700-3-2187	INSIDE WASHER	1
22	700-3-2183	BUSHING (TENSIONER)	1
23	901-01323	LOCK COLLAR, 1-3/8"	1
24	500-3-2704	TOP COVER	1
25	905-03262	CONTROL VALVE	1
26	700-3-2343	ADJUSTMENT PLATE	1
27	903-05044	ROD END EYE BOLT	1
28	700-3-2185	SPRING RETAINER	4
29	905-14022	SPRING	2
30	500-3-2705	DROP PLATE	1
31	700-2-0850	STEERING PADDLE	1
32	200-3-0877	FLANGED BUSHING	8
33	400-3-0263	EXTENSION SPRING	1
34	500-3-0675	EYE BOLT, 3/8" x 8	1
35	900-01245	BOLT, 1/2 NC x 4	4
36	900-01009	BOLT, 1/4 NC x 1	2
37	900-03112	BOLT, 1/4 NC x 2-1/4	1
38	900-01113	BOLT, 3/8 NC x 1-1/2	1
39	900-01117	BOLT, 3/8 NC x 2	3
40	900-01441	BOLT, 3/4 NC x 9-1/2	4
41	900-01013	BOLT, 1/4 NC x 1-1/2	1
42	900-01001	BOLT, 1/4 NC x 1/2	1


PARALLEL LINK SCALPER ROW FINDER COMPONENTS



PARALLEL LINK SCALPER ROW FINDER COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
43	900-01121	BOLT, 3/8 NC x 2-1/2	4
44	900-01223	BOLT, 1/2 NC x 1-1/4	5
45	200-3-2631	PARALLEL LINKAGE PIN	4
46	900-01403	BOLT, 3/4 NC x 2	4
47	900-01784	BOLT, CARRIAGE, 5/8 NC x 1-1/2	1
48	900-11031	WASHER, 1/4	2
49	900-11037	WASHER, 5/8	2
50	900-11038	WASHER, 3/4	9
51	900-11035	WASHER, 1/2	2
52	900-11033	WASHER, 3/8	1
53	900-11009	WASHER, LOCK, 1/4	1
54	900-11017	WASHER, LOCK, 3/4	8
55	900-11015	WASHER, LOCK, 5/8	2
56	900-11013	WASHER, LOCK, 1/2	4
57	900-06001	NUT, 1/4 NC	2
58	900-06504	NUT, TOP LOCK, 1/2 NC	2
59	900-06500	NUT, TOP LOCK, 3/8 NC	8
60	900-06006	NUT, 3/8 NF	2
61	900-06496	NUT, TOP LOCK, 1/2 NC	2
62	900-06015	NUT, 3/4 NC	8
63	900-06145	NUT, SPIRALOCK, 5/8 NC	9
64	900-06143	NUT, SPIRALOCK, 1/2 NC	4
65	900-06013	NUT, 5/8 NC	3
66	900-06510	NUT, TOP LOCK, 3/4 NC	4
67	900-06005	NUT, 3/8 NC	2
68	900-06009	NUT, 1/2 NC	3


ROW FINDER PARALLEL LINK MOUNT



ROW FINDER PARALLEL LINK MOUNT

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1080	UPPER MOUNT	1
2	500-2-1248	ROW FINDER	1
3	500-2-1081	H-ARM	1
4	500-3-0991	CONNECTING ARM (5/8" HOLES)	1
5	500-3-0992	CONNECTING ARM (3/4" HOLES)	1
6	500-2-1079	LOWER MOUNT	1
7	500-2-1029	HORIZONTAL MOUNT	1
8	905-21400	CYLINDER, 3-1/2 x 8	1
	905-21380	- SEAL KIT (PRINCE CYLINDERS ONLY)	
	905-21401	- SEAL KIT (MONARCK CYLINDERS ONLY)	
9	200-3-2631	PARALLEL LINK PIN	4
10	900-06145	SPIRALOCK NUT, 5/8 NC	4
11	900-06510	TOP LOCK NUT, 3/4 NC	4
12	200-3-1445	U-BOLT, 1/2 NC x 4 x 3	2
13	200-3-1447	U-BOLT, 1/2 NC x 2 x 5-1/4	2
14	900-06143	SPIRALOCK NUT, 1/2 NC	12
15	200-3-0024	U-BOLT, 3/4 NC x 6 x 5-1/2	2
16	900-11017	LOCK WASHER, 3/4	4
17	900-06015	NUT, 3/4 NC	4
18	500-2-1474	ADJUSTABLE CYLINDER EAR WELD	1
19	900-01225	BOLT, 1/2 NC X 1-1/2	4
	500-1-0182	ROW FINDER REAR TUBE MOUNT KIT	


ROW FINDER PARALLEL LINK MOUNT (44" STRUTS)



ROW FINDER PARALLEL LINK MOUNT (44" STRUTS)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1254	UPPER MOUNT	1
2	500-2-1248	ROW FINDER	1
3	500-2-1081	H-ARM	1
4	500-3-0991	CONNECTING ARM (5/8" HOLES)	1
5	500-3-0992	CONNECTING ARM (3/4" HOLES)	1
6	500-2-1255	LOWER MOUNT	1
7	500-2-1029	HORIZONTAL MOUNT	1
8	905-21400	CYLINDER, 3-1/2" x 8	1
	905-21380	- SEAL KIT (PRINCE CYLINDERS ONLY)	
	905-21401	- SEAL KIT (MONARCK CYLINDERS ONLY)	
9	200-3-2631	PARALLEL LINK PIN	4
10	900-06145	SPIRALOCK NUT, 5/8 NC	4
11	900-06510	TOP LOCK NUT, 3/4 NC	4
12	200-3-1445	U-BOLT, 1/2 NC x 4 x 3	2
13	200-3-1447	U-BOLT, 1/2 NC x 2 x 5-1/4	2
14	900-06143	SPIRALOCK NUT, 1/2 NC	12
15	900-01437	BOLT, 3/4 NC x 8-1/2	2
16	900-03463	EYE BOLT, 3/4 NC x 6	2
17	900-11017	LOCK WASHER, 3/4	20
18	900-06015	NUT, 3/4 NC	20
19	500-2-1474	ADJUSTABLE CYLINDER EAR WELD	1
20	900-01225	BOLT, 1/2 NC X 1-1/2	4
21	900-02356	BOLT, 5/16 NC X 1-3/4	2
22	900-31071	BOLT, STACKING 5/16 UNC	2
23	500-2-1233	SCALPER SET BACK WELD - RH	1
24	500-2-1231	SCALPER SET BACK WELD - LH	1
25	500-2-1234	SCALPER CROSS TUBE WELD	1
26	900-31069	CLAMP BODY	8
27	900-31068	COVER PLATE AND BOLT	2
28	900-01403	BOLT, 3/4 NC X 2	8
29	900-01407	BOLT, 3/4 NC X 2-1/2	8
	500-1-0366	ROW FINDER REAR TUBE MOUNT KIT (44" STRUTS)	


ROW FINDER ASSY - POWER BEYOND VALVE



ROW FINDER ASSY - POWER BEYOND VALVE


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1249	PIVOT MOUNT WELD	1
2	500-2-1250	TOP COVER - ROW FINDER (POWER BEYOND VALVE)	1
3	500-3-2705	PLATE - DROP PLATE	1
4	700-2-0850	STEERING PADDLE WELD	1
5	700-2-0851	PIVOT WELD	1
6	700-2-0853	SPRING TENSIONER WELD	1
7	700-2-0854	FINGER MOUNT WELD	2
8	700-2-0856	THREADED ROD - ROW FINDER	1
9	700-3-0383	OILITE BUSHING - FF-1618-1	4
10	700-3-2170	SHAFT HORIZONTAL PIVOT	1
11	700-3-2182	TUBE-DOWN PRESURE BAR (PAINTED)	1
12	700-3-2183	BUSHING - DOWN PRESSURE SPRING	1
13	700-3-2185	COMPRESSION SPRING RETAINER	4
14	700-3-2186	INNER PIVOT BRACKET - ROW FINDER	1
15	700-3-2187	INSIDE WASHER - EYEBOLT	1
16	700-3-2188	FINGER - LH	1
17	700-3-2189	FINGER - RH	1
18	700-3-2343	ADJUSTMENT PLATE - ROW FINDER	1
19	900-01001	.25 UNC X 1/2 BOLT	1
20	900-01013	HEX BOLT 1/4 NC X 1 1/2 GD5 ZP	1
21	900-01105	3/8-16 X .75" HEX BOLT	2
22	900-01113	3/8NC X 1-1/2 HEX BOLT GR 5	1
23	900-01117	3/8 NC X 2 HEX BOLT GR 5	3
24	900-01121	3/8-16 NC X 3 HEX BOLT SS	4
25	900-01223	BOLT, HEX HEAD, 1/2" X 1-1/4", GR5, ZP	4
26	900-01245	1/2 X 4 HEX BOLT GR5 ZP	2
27	900-01341	HEX BOLT 5/8 NC X 1-1/2 NC GR5 ZP	2
28	900-03076	3/4-10 X 4.5 FULL THREAD HEX BOLT	1
29	900-03112	1/4-20 X 2 1/4 HEX HEAD GR8ZP	1
30	900-03465	EYE BOLT 5/8 X 3	1
31	900-06006	NUT, HEX HEAD 3/8 NF, ZP	2
32	900-06013	NUT, HH, 5/8-11, ZP	2
33	900-06015	NUT, HH, 3/4-10, ZP	1
34	900-06139	3/8 NC FLANGED WHIZ NUT	2
35	900-06143	1/2 NC SPIRALOCK NUT ZP GR5	4
36	900-06145	5/8 WHIZ NUT	4
37	900-06496	1/4-20 TOP LOCK HEX NUT	2
38	900-06500	NUT HEX 3/8 TOP LOCK	8
39	900-06504	NUT, LOCK, TOP, 1/2-13, GR C ZP	2
40	900-06508	NUT HEX 5/8 UNC TOP LOCK	2
41	900-11009	1/4 SPRING LOCK WASHER ZP	1
42	900-11015	WASHER, LOCK, 5/8, ZP	1
43	900-11037	WASHER, FLAT, 5/8"	2
44	903-05044	EYEBOLT - ROD END	1
45	905-03262	ROW FINDER VALVE	1
46	905-14007	SPRING - 1.245 OD X .148 WIRE X .4029 P X 7.75 LONG	1
47	905-14022	SPRING - 1.25 OD X .105 WIRE X 4.00 LONG X 12.5 COILS	2
48	905-15024	ZERK 1/4-28 UNF STRAIGHT	2

REAR STEER HYDRAULIC COMPONENTS




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	905-03263	SELF-CENTERING REAR STEER MANIFOLD	1
2	500-3-2619	MANIFOLD MOUNT	1
3	905-19154	HOSE, 3/8 x 115.0, 8MB x 6FJX (<i>SHORT HITCH</i>)	4
	905-19139	HOSE, 3/8 x 150.0, 8MB x 6FJX (<i>LONG HITCH</i>)	
4	905-19118	HOSE, 3/8 x 36.00, 6FJX x 6FJX	4
5	905-19193	HOSE, 3/8 x 106.0, 6FJX x 6FJX	2
	905-19255	HOSE, 3/8 x 76.0, 6FJX x 6FJX	
6	905-19182	HOSE, 3/8 x 114.0, 6FJX x 6FJX	2
	905-19152	HOSE, 3/8 x 84.0, 6FJX x 6FJX	
7	905-21452	DOUBLE CYLINDER, 1-1/4 x 2-1/2 x 4	1
8	905-19126	QUICK COUPLER	4
9	905-03114	ADAPTER, 90° ELBOW, 6MJ x 8MB	4
10	905-03120	ADAPTER, STRAIGHT, 6MJ x 6MB	5
11	905-03163	ADAPTER, 90° ELBOW, 6MJ x 6FJX	3
12	905-03264	ADAPTER, 90° ELBOW, 6MJ x 6MB	3
13	500-3-2837	ORANGE HOSE LABEL	2
14	500-3-2843	WHITE HOSE LABEL	1
15	500-3-2842	GREY HOSE LABEL	1
16	200-3-0017	U-BOLT, 5/8 NC x 4 x 7-1/4	2
17	900-06145	NUT, SPIRALOCK, 5/8 NC	2
18	900-01085	BOLT, 5/16 NC x 4-1/2	2
19	900-06137	NUT, SPIRLOCK, 5/16 NC	2
	500-1-0417	HOSE KIT, REAR STEER (88"-110") <i>*DOES NOT INCLUDE CYLINDER*</i>	
	500-1-0418	HOSE KIT, REAR STEER (132"-154") <i>*DOES NOT INCLUDE CYLINDER*</i>	

ROW FINDER HYDRAULIC COMPONENTS




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	905-19155	HOSE, 3/8 x 120.0", 6FJX x 6FJX	5
2	905-03120	ADAPTER, STRAIGHT, 6MJ x 6MB	6
3	905-03163	ADAPTER, 90° ELBOW, 6MJ x 6FJX	10
4	905-03210	ADAPTER, STRAIGHT, 6MJ x 12MB	3
5	905-03198	ADAPTER, STRAIGHT, 6MJ x 10MB	2
6	905-03220	ADAPTER, 1/16 RESTRICTOR, 6FJ x 6MJ	1
	500-1-0393	ROW FINDER HOSE KIT	

SCALPER HYDRAULIC COMPONENTS




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	905-19154	HOSE, 3/8 x 115.0, 8MB x 6FJX (<i>SHORT HITCH</i>)	2
	905-19139	HOSE, 3/8 x 150.0, 8MB x 6FJX (<i>LONG HITCH</i>)	
2	905-19117	HOSE, 3/8 x 57.0, 6FJX x 6FJX	2
	905-19226	HOSE, 3/8 x 96.0, 6FJX x 6FJX	
3	905-19170	HOSE, 3/8 x 64.0, 6FJX x 6FJX	2
	905-19182	HOSE, 3/8 x 114.0, 6FJX x 6FJX	
4	905-21400	CYLINDER, 3-1/2 x 8	2
5	905-19126	QUICK COUPLER	2
6	905-03127	ADAPTER, TEE, 6MJ x 6MJ x 6FJX	2
7	905-03163	ADAPTER, 90° ELBOW, 6MJ x 6FJX	1
8	905-03277	ADAPTER, STRAIGHT, 6FJ x 6MJ	1
9	905-03114	ADAPTER, 90° ELBOW, 6MJ x 8MB	4
10	500-3-2841	VIOLET HOSE LABEL	
	500-1-0427	HOSE KIT, RIGID SCALPERS 1222 <i>*DOES NOT INCLUDE CYLINDER*</i>	
	500-1-0428	HOSE KIT, RIGID SCALPERS 630 - 922 <i>*DOES NOT INCLUDE CYLINDER*</i>	
	500-1-0429	HOSE KIT, RIGID SCALPERS 430 - 622 <i>*DOES NOT INCLUDE CYLINDER*</i>	

DOOR OPENER HYDRAULIC COMPONENTS



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	905-19154	HOSE, 3/8 x 115.0, 8MB x 6FJX (<i>SHORT HITCH</i>)	2
	905-19139	HOSE, 3/8 x 150.0, 8MB x 6FJX (<i>LONG HITCH</i>)	
2	905-19124	HOSE, 3/8 x 25.0, 6FJX x 6FJX	2
3	905-21453	CYLINDER, 2 x 12	1
4	905-19126	QUICK COUPLER	2
5	905-03282	ADAPTER, 45° ELBOW, 6MJ x 6FJX	4
6	905-03115	ADAPTER, STRAIGHT, 6MJ x 8MB	1
7	905-03114	ADAPTER, 90° ELBOW, 6MJ x 8MB	1
8	500-3-2840	BLUE HOSE LABEL	2
9	905-03261	RESTRICTOR, 6FJ X 6MJ X 1/32 HOLE	2
	500-1-0431	HOSE KIT, DOOR OPENER (<i>DOES NOT INCLUDE CYLINDER</i>)	

RIGID STRUT PLUMBING COMPONENTS




RIGID STRUT PLUMBING COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-3-2895	FLOW DIVIDER MOUNT	1
2	905-03274	FLOW DIVIDER	1
3	905-19154	HOSE, 3/8 x 115.0, 8MB x 6FJX (<i>SHORT HITCH</i>)	2
	905-19139	HOSE, 3/8 x 150.0, 8MB x 6FJX (<i>LONG HITCH</i>)	
4	905-19124	HOSE, 3/8 x 25.0, 6FJX x 6FJX	2
5	905-19169	HOSE, 3/8 x 54.0, 6FJX x 6FJX (<i>66" STRUT SPACING</i>)	2
	905-19255	HOSE, 3/8 x 76.0, 6FJX x 6FJX (<i>88" - 110" STRUT SPACING</i>)	
	905-19193	HOSE, 3/8 x 106.0, 6FJX x 6FJX (<i>132" - 154" STRUT SPACING</i>)	
6	905-19125	HOSE, 3/8 x 62.0, 6FJX x 6FJX (<i>66" STRUT SPACING</i>)	2
	905-19152	HOSE, 3/8 x 84.0, 6FJX x 6FJX (<i>88" - 110" STRUT SPACING</i>)	
	905-19182	HOSE, 3/8 x 114.0, 6FJX x 6FJX (<i>132" - 154" STRUT SPACING</i>)	
7	905-19175	HOSE, 3/8 x 144.0, 6FJX x 6FJX (<i>198" STRUT SPACING</i>)	0 / 2
8	905-19175	HOSE, 3/8 x 144.0, 6FJX x 6FJX (<i>198" STRUT SPACING</i>)	0 / 2
9	905-21400	CYLINDER, 3-1/2 x 8	2 / 4
10	905-19126	QUICK COUPLER	2
11	905-03114	ADAPTER, 90° ELBOW, 6MJ x 8MB	4 / 8
12	905-03115	ADAPTER, STRAIGHT, 6MJ x 8MB	2
13	905-03120	ADAPTER, STRAIGHT, 6MJ x 6MB	4 / 8
14	905-03265	ADAPTER, PLUG, 6MB	4 / 0
15	500-3-2839	GREEN HOSE LABEL	2
16	200-3-0017	U-BOLT, 5/8 NC x 4 x 7-1/4	1
17	900-06145	NUT, SPIRALOCK, 5/8 NC	2
18	900-01037	BOLT, 1/4 NC x 5	2
19	900-06135	NUT, SPIRALOCK, 1/4 NC	2
	500-1-0424	HOSE KIT, RIGID STRUTS (<i>66" STRUT SPACING</i>) *	
	500-1-0425	HOSE KIT, RIGID STRUTS (<i>88" - 110" STRUT SPACING</i>) *	
	500-1-0426	HOSE KIT, RIGID STRUTS (<i>132" - 154" STRUT SPACING</i>) *	
	500-1-0422	HOSE KIT, RIGID STRUTS (<i>4 PAIR SMALL TIRE STRUTS</i>) *	

* HOSE KITS DO NOT INCLUDE CYLINDERS

STEERABLE STRUT PLUMBING COMPONENTS




STEERABLE STRUT PLUMBING COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-3-2895	FLOW DIVIDER MOUNT	1
2	905-03274	FLOW DIVIDER	1
3	905-19154	HOSE, 3/8 x 115.0, 8MB x 6FJX (<i>SHORT HITCH</i>)	2
	905-19139	HOSE, 3/8 x 150.0, 8MB x 6FJX (<i>LONG HITCH</i>)	
4	905-19124	HOSE, 3/8 x 25.0, 6FJX x 6FJX	2
5	905-19196	HOSE, 3/8 x 72.0, 6FJX x 6FJX (<i>66" STRUT SPACING</i>)	4
	905-19226	HOSE, 3/8 x 96.0, 6FJX x 6FJX (<i>88" - 110" STRUT SPACING</i>)	
	905-19155	HOSE, 3/8 x 120.0, 6FJX x 6FJX (<i>132" - 154" STRUT SPACING</i>)	
6	905-19175	HOSE, 3/8 x 144.0, 6FJX x 6FJX (<i>198" STRUT SPACING</i>)	0 / 4
7	905-21400	CYLINDER, 3-1/2 x 8	2 / 4
8	905-19126	QUICK COUPLER	2
9	905-03114	ADAPTER, 90° ELBOW, 6MJ x 8MB	4 / 8
10	905-03115	ADAPTER, STRAIGHT, 6MJ x 8MB	2
11	905-03120	ADAPTER, STRAIGHT, 6MJ x 6MB	4 / 8
12	905-03265	ADAPTER, PLUG, 6MB	4 / 0
13	500-3-2839	GREEN HOSE LABEL	2
14	200-3-0017	U-BOLT, 5/8 NC x 4 x 7-1/4	1
15	900-06145	NUT, SPIRALOCK, 5/8 NC	2
16	900-01037	BOLT, 1/4 NC x 5	2
17	900-06135	NUT, SPIRALOCK, 1/4 NC	2
	500-1-0419	HOSE KIT, STEERABLE STRUTS (<i>66" STRUT SPACING</i>) *	
	500-1-0420	HOSE KIT, STEERABLE STRUTS (<i>88" - 110" STRUT SPACING</i>) *	
	500-1-0421	HOSE KIT, STEERABLE STRUTS (<i>132" - 154" STRUT SPACING</i>) *	
	500-1-0422	HOSE KIT, STEERABLE STRUTS (<i>4 PAIR SMALL TIRE STRUTS</i>) *	

* HOSE KITS DO NOT INCLUDE CYLINDERS


HARDLINE COMPONENTS



HARDLINE COMPONENTS


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1463	HARDLINE MOUNT WELD	1
2	500-2-1451	RIGID CENTER HARDLINE	2
3	500-2-1464	FRONT HARDLINE COVER PLATE WELD	1
4	500-3-3007	CENTER HYDRAULIC HOLDER CAP	1
5	500-2-1449	RIGID STRAIGHT HARDLINE	8
6	500-3-3009	WIDE CLAMP BLOCK TOP PLATE	3
7	500-3-3010	CENTER CLAMP BLOCK TOP PLATE	1
8	500-3-3005	BACK INSIDE PLATE - HARDLINE COVER	1
9	500-3-3006	BACK OUTSIDE PLATE - HARDLINE COVER	1
10	905-03280	ADAPTER, BULKHEAD, 6MJ X 6MJBH	20
11	904-01313	RUBBER GROMMET	10
12	900-31090	SINGLE BORE SAFETY LOCK PLATE	20
13	900-31091	SINGLE BORE CLAMP STACKING BOLT	20
14	900-31087	SINGLE BORE CLAMP BLOCK	56
15	900-01011	BOLT, 1/4 NC X 1-1/4	8
16	900-01111	BOLT, 3/8 NC X 1-1/4	8
17	900-01005	BOLT, 1/4 NC X 3/4	4
18	900-06136	NUT, FLANGE SPIRALOCK 1/4 NC	4
19	900-06139	NUT, SPIRALOCK 3/8 NC	8
20	900-11033	WASHER, 3/8	8
21	900-11031	WASHER, 1/4	4

LONG HITCH PTO DRIVE SHAFT COMPONENTS




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	903-18240	SSL / AUTO-LOK REPAIR KIT, 1-3/8"	1
	903-18255	SSL / AUTO-LOK REPAIR KIT, 1-3/4"	
2	903-18241	WWCV AUTO-LOK YOKE, 1-3/8"	1
	903-18256	WWCV AUTO-LOK YOKE, 1-3/4"	
3	903-17712	CAT 5 80 E CV CROSS & BEARING KIT	1
4	903-18242	CV CENTER HOUSING	1
5	903-18243	YOKE & SHAFT (1.69-20 SPLINE), 1-3/8"	1
	903-18257	YOKE & SHAFT (1.69-20 SPLINE), 1-3/4"	
6	903-18244	GUARD REPAIR KIT	1
7	903-17455	SAFETY SIGN	2
8	903-18258	OUTER GUARD	1
9	903-18259	INNER GUARD	1
10	903-18247	SAFETY SIGN	
11	903-18248	GUARD REPAIR KIT	1
12	903-18260	YOKE, TUBE, & SLIP SLEEVE	1
13	903-18250	44E CROSS & BEARING KIT	1
14	903-17639	YOKE	1
	903-18216	LONG HITCH PTO DRIVE SHAFT, COMPLETE 1-3/8"	
	903-18217	LONG HITCH PTO DRIVE SHAFT, COMPLETE 1-3/4"	

LONG HITCH DRIVELINE COMPONENTS




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	903-17639	YOKE	1
2	903-18250	44E CROSS KIT	2
3	903-18430	YOKE & SHAFT (1.69-20 SPLINE)	1
4	903-18248	GUARD REPAIR KIT	2
5	903-18431	OUTER GUARD	1
6	903-17455	SAFETY SIGN	1
7	903-18247	SAFETY SIGN	1
8	903-18432	INNER GUARD	1
9	903-18433	YOKE, TUBE & SLIP SLEEVE	1
10	903-17721	OVERRUNNING CLUTCH ASSY	1
11	903-18434	SETSCREW, 3/8 NC x 3/8	2
	903-18423	COMPLETE LONG HITCH DRIVE SHAFT, COMPLETE	

PTO DRIVE SHAFT COMPONENTS




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	903-18106	SAFETY SLIDE LOCK REPAIR KIT, 1-3/8"	1
	903-17772	SAFETY SLIDE LOCK REPAIR KIT, 1-3/4"	
2	903-18116	SAFETY SLIDE LOCK YOKE, 1-3/8"	1
	903-18108	SAFETY SLIDE LOCK YOKE, 1-3/4"	
3	903-17525	44R CROSS & BEARING KIT	1
4	903-18109	YOKE & SHAFT (1.69-20 SPLINE)	1
5	903-17774	NYLON REPAIR KIT	2
6	903-17455	SAFETY SIGN	1
7	903-18110	OUTER GUARD	1
8	903-11111	INNER GUARD	1
9	903-17456	SAFETY SIGN	1
10	903-18112	YOKE, TUBE, & SLIP SLEEVE	1
11	903-17721	OVERRUNNING CLUTCH	1
12	903-18210	OVERRUNNING CLUTCH REPAIR KIT	1
	903-18088	COMPLETE PTO DRIVE SHAFT, COMPLETE 1-3/8"	
	903-18089	COMPLETE PTO DRIVE SHAFT, COMPLETE 1-3/4"	

PTO DRIVE SHAFT COMPONENTS (CONSTANT VELOCITY)



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	903-17427	SSL / AUTO-LOK REPAIR KIT, 1-3/8"	1
	903-17772	SSL / AUTO-LOK REPAIR KIT, 1-3/4"	
2	903-18334	WWCV AUTO-LOK YOKE, 1-3/8"	1
	903-18327	WWCV AUTO-LOK YOKE, 1-3/4"	
3	903-18328	AB8/AW24/CAT 6 80° PBL CROSS KIT	1
4	903-18329	WWCV CENTER HOUSING	1
5	903-18405	WWCV YOKE & SHAFT (1.69-20 SPLINE)	1
6	-	OUTER GUARD	1
7	903-18395	GUARD REPAIR KIT	2
8	903-17455	SAFETY SIGN	1
9	903-17456	SAFETY SIGN	1
10	903-18248	GUARD REPAIR KIT	
11	-	INNER GUARD	1
12	903-17718	YOKE, TUBE, & SLIP SLEEVE	1
13	903-17525	44E CROSS & BEARING KIT	1
14	903-17721	OVERRUNNING CLUTCH	1
	903-17717	GUARD SET * INCLUDES #6, #10 *	
	903-18406	COMPLETE PTO DRIVE SHAFT, COMPLETE 1-3/8"	
	903-18407	COMPLETE PTO DRIVE SHAFT, COMPLETE 1-3/4"	

PTO DRIVE SHAFT COMPONENTS




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	903-18106	SSL/AUTO-LOK REPAIR KIT 26-15120	1
	903-17772	SSL/AUTO-LOK REPAIR KIT 26-13387	1
2	903-18116	SAFETY SLIDE LOCK YOKE ASM 44011-1007	1
	903-18108	SAFETY SLIDE LOCK YOKE ASM	1
3	903-17525	CROSS KIT 44E	2
4	903-18449	YOKE & SHAFT (1.69-20 SPLINE) 99-26085	1
5	903-18450	OUTER GUARD 97-26085	1
6	903-18248	GUARD REPAIR KIT 19-15121	2
7	903-17455	SAFETY SIGN 13-10021	1
8	903-17456	SAFETY SIGN 13-10022	1
9	903-18451	INNER GUARD 96-26085	1
10	903-18452	YOKE, TUBE & SLIP SLEEVE 98-26085	1
11	903-17721	OVERRUNNING CLUTCH ASM. 39-10044	1
12	903-18453	JOINT & SHAFT HALF ASM. W/GUARD 93-26085	1
	903-18445	JOINT & SHAFT HALF ASM. W/GUARD 92-26086	1
13	903-18454	JOINT & SHAFT HALF ASM. 95-26085	1
	903-18446	JOINT & SHAFT HALF ASM. 95-26086	1
14	903-18447	JOINT & SHAFT HALF ASM. W/GUARD 92-26085	1
15	903-18448	JOINT & SHAFT HALF ASM. 95-26085	1
	903-18455	PTO SHAFT, 1-3/8" YOKE	1
	903-18456	PTO SHAFT, 1-3/4" YOKE	1

GEAR BOX COMPONENTS


NOTES:

1. GEAR RATIO IS 1.5:1 REDUCER FROM THE CROSS SHAFT
2. TORQUE 3/8-16 CAPSCREWS (ITEM 15) TO 35-40 FT-LBS
3. STAMP PART NO. AND LOT NO. IN AREA SHOWN



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	903-15291	CASTING, MACHINE BOTTOM THREADED	1
2	903-15292	CASTING, MACHINE TOP HALF	1
3	903-15591	SUBA, R600 STUB SHAFT/GEAR	2
4	903-15592	SHAFT, CROSS R600 1.5i SPLINED	1
5	903-15593	SPACER, 2.25 X 1.939, 1.324	1
6	903-15595	GEAR, R600 1.50:1 SPLINE 20 TOOTH	1
7	901-01151	BEARING CONE 3782	2
8	901-01153	BEARING CUP 3720	2
9	901-01328	BEARING CONE 25580	2
10	901-01150	BEARING CONE 25581	2
11	901-01152	BEARING CUP 25520	4
12	901-09125	SEAL, TC-1.750-2.437-.312	3
13	903-15594	SEAL, END CAP, 2.45-.312	1
14	900-39030	RETAINING RING, 1.750	2
15	900-03033	BOLT, 3/8-16 X 2.25 SHCS	16
16	905-03078	PLUG, 1/2-14 NPT SCHD W/3M	2
17	905-01159	BUSHING, 1/2 NPT TO 1/8 NPT	1
18	905-03080	PLUG, VENT 5 PSI	1
19	903-15411	DIP STICK, STANDARD	1
-	903-15399	GEAR BOX, COMPLETE	1


HITCH COMPONENTS




HITCH COMPONENTS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1325	LONG HITCH FRAME	1
2	500-2-1352	SHORT HITCH FRAME	1
3	505-3-0831	HITCH, CAT-3	2
4	905-07123	SAFETY CHAIN	2
5	500-3-2710	TOP PTO SHIELD	1
6	903-18007	PTO BELL	1
7	500-3-2164	GUARD BRACKET	1
8	901-01185	BEARING, 4-BOLT 1-3/4	2
9	700-3-2357	PTO TRANSFER SHAFT	1
10	903-18423	JUMPER DRIVELINE	1
11	905-21400	CYLINDER, 3-1/2 x 8	2
12	100-3-3333	KEY, 3/8 x 3/8 x 2	2
13	900-02930	BOLT, 1 NC x 7	4
14	900-01519	BOLT, 1 NC x 3	2
15	900-01527	BOLT, 1 NC x 4	4
16	900-01345	BOLT, 5/8 NC x 2	8
17	900-01109	BOLT, 3/8 NC x 1	6
18	900-01005	BOLT, 1/4 NC x 3/4	4
19	900-11033	WASHER, 3/8	6
20	900-11015	WASHER, LOCK 5/8	8
21	900-11011	WASHER, LOCK 3/8	2
22	900-11021	WASHER, LOCK 1	4
23	900-06514	NUT, TOP LOCK 1 NC	6
24	900-06005	NUT, 3/8 NC	6
25	900-06013	NUT, 5/8 NC	8
26	900-06135	NUT, SPIRALOCK 1/4 NC	4
27	900-06019	NUT, 1 NC	4
28	500-2-0792	SHORT HITCH HOSE KIT	-
29	500-2-1243	LONG HITCH HOSE KIT	-
30	500-2-1426	LONG HITCH ELECTRICAL EXTENSION KIT	-
-	500-1-0403	SHORT HITCH, COMPLETE KIT	-
-	500-2-1326	LONG HITCH, COMPLETE KIT	-

S-SERIES SWING HITCH




EXPLODED VIEW



S-SERIES SWING HITCH


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	500-2-1568	SWING HITCH BASE WELDMENT	1
2	500-2-1569	SWING HITCH TUBE WELDMENT	1
3	500-2-1570	SWING HITCH PIN WELDMENT	1
4	500-3-4861	THRUST WASHER - HITCH	2
5	500-3-4876	SWING HITCH 3" WASHER	1
6	505-3-0831	HITCH TONGUE COMP CAT3	1
7	900-01519	BOLT, HH, 1-8 x 3, GR5 ZP	1
8	900-02930	BOLT, HH, 1-8 x 7, GR5 ZP	2
9	900-06514	NUT, LOCK, 1" NC, TOP, ZP	2
10	900-23084	PIN, COTTER, 3/8 X 3-1/2	1
11	700-3-0730	SPLIT BUSHING - 3 ID X 3.5OD X 3 LONG	2
12	905-07123	TOW CHAIN SAFETY 21,000 LB	1
13	905-21400	HYD CYL - 3.5 X 8	1
14	905-21456	HYD CYL - 3.5 X 8	1
	500-1-0476	S SERIES SWING HITCH	

HITCH HYDRAULIC COMPONENTS



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	905-19176	HOSE, 3/8 x 105.0, 8MB x 6FJX (SHORT HITCH)	1
	905-19279	HOSE, 3/8 x 140.0, 8MB x 6FJX (LONG HITCH)	
2	905-19154	HOSE, 3/8 x 115.0, 8MB x 6FJX (SHORT HITCH)	1
	905-19139	HOSE, 3/8 x 150.0, 8MB x 6FJX (LONG HITCH)	
3	905-19126	QUICK COUPLER	2
4	905-03114	ADAPTER, 90° ELBOW, 6MJ x 8MB	2
5	905-21400	CYLINDER, 3-1/2 x 8	1
-	500-2-0792	HOSE KIT, SHORT HITCH	-
-	500-2-1242	HOSE KIT, LONG HITCH	-
-	500-2-0789	HYDRAULIC KIT, SHORT HITCH (INCLUDES CYLINDER)	-
-	500-2-1243	HYDRAULIC KIT, LONG HITCH (INCLUDES CYLINDER)	-

LIGHT KIT COMPONENTS



6-WIRE HARNESS
(NOT SHOWN)


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	200-3-0017	U-BOLT 5/8 X 4 X 7.5 X 1.5	6
2	500-2-1540	S SERIES FIELD LIGHT TOP WELDMENT	1
3	500-2-1541	S SERIES FIELD LIGHT BASE WELDMENT	1
4	500-3-1696	SMV SIGN	1
5	500-3-4801	SMV MOUNT	1
6	500-3-2196	12 ROW FUD WIRE HARNESS	1
7	500-3-5282	LIGHT MOUNT- GROTE HALF MOON	1
8	900-01001	BOLT, HH 1/4 X 1/2 G5 ZP	4
9	900-01005	1/4-20 X 3/4 ZP HEX BOLT	2
10	900-01011	BOLT, HH 1/4 X 1-1/4 G5 ZP	4
11	900-06013	NUT, HH, 5/8-11, ZP	2
12	900-06135	WHIZ NUT - 1/4 - 20	5
13	900-06139	3/8 NC FLANGED WHIZ NUT	2
14	900-06496	1/4-20 TOP LOCK HEX NUT	2
15	900-35000	U-BOLT 3/8 X 6 X 5 X 1.5	1
16	900-42065	SNAPPER PIN .25 X 3.00 USABLE LENGTH	1
17	904-01346	TRILLIANT WORK LIGHT	1
18	904-01363	GROTE, HALF MOON LIGHT- AMBER	1
19	904-01364	GROTE, HALF MOON LIGHT- RED	4
20	904-01365	VIBRATION DAMPING LOOP CLAMP 3/8"	1
	500-2-1542	S SERIES FIELD LIGHT ASSEMBLY (REF. 1,2,3,11,16)	
	500-2-1770	LIGHT MOUNT ASSEMBLY - GROTE HALF MOON AMBER (REF. 7,8,10,12,18,20)	
	500-2-1777	LIGHT MOUNT ASSEMBLY - GROTE HALF MOON RED (REF. 7,8,10,12,19,20)	
	500-1-0396	LIGHT KIT	

BOLT TORQUE CHART

SAE Series Torque Chart

Always tighten hardware to these values unless a different torque value or tightening procedure is listed for a specific application. Fasteners must always be replaced with the same grade as specified in the manual parts list.



Make sure fastener threads are clean and you properly start thread engagement.

SAE Bolt Head Identification		 SAE Grade 2 (No Dashes)		 SAE Grade 5 (3 Radial Dashes)		 SAE Grade 8 (6 Radial Dashes)	
Ⓐ Diameter (Inches)	Wrench Size	MARKING ON HEAD					
		SAE 2		SAE 5		SAE 8	
		ft./lb.	(Nm)	ft./lb.	(Nm)	ft./lb.	(Nm)
1/4"	7/16'	6	(8)	10	(13)	14	(18)
5/16'	1/2"	12	(17)	19	(26)	27	(37)
3/8"	9/16"	23	(31)	35	(47)	49	(67)
7/16"	5/8"	36	(48)	55	(75)	78	(106)
1/2"	3/4"	55	(75)	85	(115)	120	(163)
9/16"	13/16"	78	(106)	121	(164)	171	(232)
5/8"	15/16"	110	(149)	170	(230)	240	(325)
3/4"	1-1/8"	192	(261)	297	(403)	420	(569)
7/8"	1-5/16"	306	(416)	474	(642)	669	(907)
1"	1-1/2"	350	(475)	680	(925)	1020	(1383)
1-1/8"	1-11/16"	450	(610)	885	(1200)	Bolt Diameter 	
1-1/4"	1-7/8"	600	(815)	1255	(1700)		
1-3/8"	2-1/16"	675	(915)	1620	(2200)		
1-1/2"	2-1/4'	920	(1250)	2200	(2900)		



Metric Series Torque Chart

Use only metric tools on metric hardware. Always tighten hardware to these values unless a different torque value or tightening procedure is listed for a specific application. Fasteners must always be replaced with the same grade.

Make sure fastener threads are clean and you properly start thread engagement.

Ⓐ Diameter & Thread Pitch (Millimeters)	Wrench Size	COARSE THREAD				FINE THREAD				Ⓐ Diameter & Thread Pitch (Millimeters)	Metric Bolt Head Identification
		MARKING ON HEAD				MARKING ON HEAD					
		Metric 8.8		Metric 10.9		Metric 8.8		Metric 10.9			
		Nm	ft./lb.	Nm	ft./lb.	Nm	ft./lb.	Nm	ft./lb.		
6x1.0	10 mm	8	6	11	8	8	6	11	8	6x1.0	 Metric Grade 8.8
8x1.25	13 mm	20	15	27	20	21	16	29	22	8x1.0	
10x1.5	16 mm	39	29	54	40	41	30	57	42	10x1.25	
12x1.75	18 mm	68	50	94	70	75	55	103	76	12x1.25	
14x2.0	21 mm	109	80	151	111	118	87	163	120	14x1.5	 Metric Grade 10.9
16x2.0	24 mm	169	125	234	173	181	133	250	184	16x1.5	
18x2.5	27 mm	234	172	323	239	263	194	363	268	18x1.5	
20 x 2.5	30 mm	330	244	457	337	367	270	507	374	20x1.5	
22 x 2.5	34 mm	451	332	623	460	495	365	684	505	22 x 1.5	
24 x 3.0	36 mm	571	421	790	583	623	459	861	635	24 x 2.0	
30 x 3.0	46 mm	1175	867	1626	1199	1258	928	1740	1283	30 x 2.0	

Typical Washer Installations



8/9/00

ABBREVIATIONS

AG	Agriculture	NC	National Course
ASAE	American Society of Agricultural Engineers	NF	National Fine
ATF	Automatic Transmission Fluid	NPSM	National Pipe Straight Mechanical
BSPP	British Standard Pipe Parallel	NPT	National Pipe Tapered
BSPTM	British Standard Pipe Tapered Male	NPT SWF	National Pipe Tapered Swivel Female
CV	Constant Velocity	Nm	Newton Meter
CCW	Counter-Clockwise	OSHA	Occupational Safety and Health Administration
CW	Clockwise	P	Pitch
DIA	Diameter	PBY	Power Beyond
EP	Extreme Pressure	psi	Pounds per Square Inch
F	Female	PTO	Power Take Off
FB	Female O-Ring Boss	QD	Quick Disconnect
FJ	Female Boss	RH	Right Hand
FJX	Female Swivel JIC	ROPS	Roll Over Protection Structure
FP	Female Pipe	RPM	Revolutions Per Minute
ft./lb	Foot Pound	RT	Right
GA	Gauge	SAE	Society of Automotive Engineers
GR (5, etc.)	Grade (5, etc.)	SMV	Slow Moving Vehicle
HHCS	Hex Head Cap Screw	UNC	Unified Coarse
HT	Heat Treated	UNF	Unified Fine
in	Inch	UNS	Unified Special
JIC	Joint Industry Council 37° Flare	ZP	Zinc Plate
kg	Kilogram		
km/h	Kilometers Per Hour		
lb	Pound		
LH	Left Hand		
LT	Left		
in	Inches		
m	Meter		
mm	Millimeter		
M	Male		
MB	Male O-Ring Boss		
MJ	Male JIC		
MJX	Male Swivel JIC		
MP	Male Pipe		
MPa	Mega Pascal		
MPH	Miles Per Hour		
N	Newton		

INDEX

ADDITIONAL EQUIPMENT	27
Rear Steer	27
Scalpers	28
Stabilizer Struts	28
Steel Flail Units.....	28

GENERAL

Abbreviations.....	126
Bolt Torque Chart	125
General Information	1
Introduction.....	Inside Front Cover
Product Warranty	Inside Back Cover
Replacement Part Warranty	128
Table of Contents	1

FIELD OPERATION

Flail Patterns.....	25
Operating the Defoliator.....	26
Preparing for Operation	24
Speed vs. Weight Ratio	24
Transporting the Unit.....	24
Turning.....	26

OPERATION

Attaching the Defoliator to the Tractor	17
Breaking-In	15
Choosing the Correct Equipment	16
Complete Attachment.....	18
Machine Settings.....	19
Flail Height.....	20
Flail Spacing	20
Machine Leveling	19
Stabilizer Wheel Position	21
Wheel Spacing	21
Pre-Operation Check List	15
Principal Components.....	14
Removing the Defoliator from Tractor	18
Scalper Settings (Optional).....	22

PARTS INDEX.....

41

SAFETY

Check Lists	12
Hazard Area	26
Operator Sign-Off Record.....	11
Safety & Instructional Decals.....	8 - 9
Safety-Alert Symbols	Inside Front Cover
Safety Rules	3 - 7

SERVICE & MAINTENANCE.....

32

Bearing Lock Collars.....	38
Belt Replacement.....	39
Belt Tension	38
Changing Gearbox Oil	34
Flail Replacement	37
Flail Spacing	36
Flail Tube Hanger Bearing.....	39
Greasing	32
Lubricants	32
Lubrication Schedule	33
10hrs	33
20hrs	33
40hrs	34
Annually	34
Lubrication Service Record.....	35
Scalpers.....	40
Wheel Spacing	36

STORAGE

31

TROUBLE SHOOTING

41 - 42

WARRANTY

Please Enter Information Below and Save For Future Reference.

Date Purchased: _____ From (Dealer): _____

Model Number: _____ Serial Number: _____

ALLOWAY STANDARD, d/b/a ALLOWAY, warrants this product to be free from defect in material and workmanship for TWELVE (12) MONTHS COMMENCING ON THE DATE OF DELIVERY OF THE PRODUCT TO THE ORIGINAL PURCHASER.

Under no circumstances will this Warranty apply in the event that the product, in the good faith opinion of ALLOWAY, has been subjected to improper operation, improper maintenance, misuse, or an accident. This Warranty does not apply in the event that the product has been materially modified or repaired by someone other than ALLOWAY, a ALLOWAY authorized dealer or distributor, and/or a ALLOWAY authorized service center; This Warranty does not cover normal wear or tear, or normal maintenance items. This Warranty also does not cover repairs made with parts other than those obtainable through ALLOWAY.

This Warranty is extended solely to the original purchaser of the product. Should the original purchaser sell or otherwise transfer this product to a third party, this Warranty does not transfer to the third party purchaser in any way. There are no third party beneficiaries of this Warranty.

ALLOWAY makes no warranty, express or implied, with respect to tires or other parts or accessories not manufactured by ALLOWAY. Their respective manufacturers, if any, provide warranties for these items, separately. ALLOWAY'S obligation under this Warranty is limited to, at ALLOWAYS' option, the repair or replacement, free of charge, of the product if ALLOWAY, in its sole discretion, deems it to be defective or in noncompliance with this Warranty. The product must be returned to ALLOWAY with proof of purchase within thirty (30) days after such defect or noncompliance is discovered or should have been discovered, routed through the dealer and distributor from whom the purchase was made, transportation charges prepaid. ALLOWAY shall complete such repair or replacement within a reasonable time after ALLOWAY receives the product. THERE ARE NO OTHER REMEDIES UNDER THIS WARRANTY. THE REMEDY OF REPAIR OR REPLACEMENT IS THE SOLE AND EXCLUSIVE REMEDY UNDER THIS WARRANTY.

THERE ARE NO WARRANTIES, WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE OF THIS WARRANTY. ALLOWAY MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, AND ALLOWAY SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY AND/OR ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

ALLOWAY shall not be liable for any incidental or consequential losses, damages or expenses, arising directly or indirectly from the product, whether such claim is based upon breach of contract, breach of warranty, negligence, strict liability in tort or any other legal theory. Without limiting the generality of the foregoing. Alloway specifically disclaims any damages relating to (i) lost profits, business, revenues or goodwill; (ii) loss of crops; (iii) loss because of delay in harvesting; (iv) any expense or loss Incurred for labor, supplies, substitute machinery or rental; or (v) any other type of damage to property or economic loss.

This Warranty is subject to any existing conditions of supply, which may directly affect ALLOWAYS' ability to obtain materials or manufacture replacement parts.

No agent, representative, dealer, distributor, serviceperson, salesperson, or employee of any company; including without limitation, ALLOWAY, its authorized dealers, distributors, and service centers, is authorized to alter, modify, or enlarge this Warranty.

This Warranty is effective only if the warranty registration card is returned within ten (10) days.

Answers to any questions regarding warranty service and locations may be obtained by contacting:

Alloway
4230 14th Ave.NW
Fargo, North Dakota 58102
701-356-4983



WARRANTY

ALLOWAY STANDARD, d/b/a ALLOWAY, warrants this product to be free from defect in material and workmanship for a period of One (1) year, ninety (90) days for Service Parts, from the date of delivery of the product to the original purchaser.

Under no circumstances will this Warranty apply in the event that the product, in the good faith opinion of ALLOWAY, has been subjected to improper operation, improper maintenance, misuse, or an accident. This Warranty does not cover normal wear or tear, or normal maintenance items.

This Warranty is extended solely to the original purchaser of the product. Should the original purchaser sell or otherwise transfer this product to a third party, this Warranty does not transfer to the third party purchaser in any way. There are no third party beneficiaries of this Warranty.

ALLOWAY'S obligation under this Warranty is limited to, at ALLOWAY'S option, the repair or replacement, free of charge, of the product if ALLOWAY, in its sole discretion, deems it, to be defective or in noncompliance with this Warranty. The product must be returned to ALLOWAY with proof of purchase within thirty (30) days after such defect or noncompliance is discovered or should have been discovered, routed through the dealer and distributor from whom the purchase was made, transportation charges prepaid. ALLOWAY shall complete such repair or replacement within a reasonable time after ALLOWAY receives the product. THERE ARE NO OTHER REMEDIES UNDER THIS WARRANTY. THE REMEDY OF REPAIR OR REPLACEMENT IS THE SOLE AND EXCLUSIVE REMEDY UNDER THIS WARRANTY.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE OF THIS WARRANTY. ALLOWAY MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, AND ALLOWAY SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY AND/OR ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

ALLOWAY shall not be liable for any incidental or consequential losses, damages or expenses, arising directly or indirectly from the product, whether such claim is based upon breach of contract, breach, of warranty, negligence, strict liability in tort or any other legal theory. Without limiting the generality of the foregoing, Alloway specifically disclaims any damages relating to (i) lost profits, business, revenues or goodwill; (ii) loss of crops; (iii) loss because of delay in harvesting; (iv) any expense or loss incurred for labor, supplies, substitute machinery or rental; or (v) any other type of damage to property or economic loss.

This Warranty is subject to any existing conditions of supply, which may directly affect ALLOWAYS' ability to obtain materials or manufacture replacement parts.

No agent, representative, dealer, distributor, service person, salesperson, or employee of any company, including without limitation, ALLOWAY, Its authorized dealers, distributors, and service centers, IS authorized to alter, modify, or enlarge this Warranty.

Answers to any questions regarding warranty service and locations may be obtained by contacting:

Alloway
4230 14th Ave.NW
Fargo, North Dakota 58102
701-356-4983



PART NUMBER
500-5-0024



Quality • Innovation

Alloway Standard Industries
4230 14th Avenue NW
Fargo, North Dakota 58102

Local/Intl: 1-701-356-4983
Toll Free: 1-877-275-8714
Fax: 1-701-356-4985